



Master Project **Bin Picking Project**

Puneet Singh Arora

Immatriculation Number :- 1056132

Examiner: Prof. Micheal Wagner

Date of submission: 07/24/2024

Formale Erklärung der Urheberschaft

Ich, der/die Unterzeichnete, erkläre hiermit förmlich, dass ich der/die alleinige Verfasser/in dieses Projektberichts bin und den gesamten Inhalt unabhängig verfasst habe. Ich habe diesen Bericht oder Teile davon noch nie einer anderen Institution zur Begutachtung vorgelegt. Darüber hinaus habe ich keine anderen als die im Bericht ausdrücklich angegebenen Quellen und Hilfsmittel benutzt. Alle direkten und indirekten Zitate sind deutlich als solche gekennzeichnet.

Datum: 24. Juli 2024

Ort: Rosenheim

Puneet Singh Arora



Abstract

In this Project a a solution to the complex problem of robotic bin picking in unstructured environments was developed, with a key emphasis on utilizing open-source software tools. A meticulously calibrated stereo camera system was employed to capture high-resolution images of the bin's contents from multiple perspectives. Dense and accurate depth maps, enabling faithful 3D reconstruction of the scene even in the presence of clutter and occlusions, were generated through analysis of the disparities between left and right images. Data analysis and visualization for this project were conducted using Python 3.11 leveraging the open-source libraries OpenCV, NumPy, and Matplotlib also the open source codes from Allied Vision which include important library functions for the proper functioning of cameras like shutter closing and opening ,white balance, shutter timing .

Recognizing the challenges posed by overlapping objects, varying lighting conditions, and complex geometries, a novel algorithm tailored specifically for bin picking applications was devised.

The system's performance was evaluated through testing in a simulated scenario, encompassing a range of object types, sizes, materials, and bin configurations. Results consistently demonstrated the system's robustness, accuracy, and adaptability, even in challenging conditions such as varying illumination, reflective surfaces, and complex object geometries. This project constitutes a significant advancement in the field of robotic bin picking, paving the way for wider adoption of automation in manufacturing, logistics, and other industries where the handling of unstructured objects is a critical bottleneck. By overcoming the limitations of traditional approaches, this stereo vision-based system offers a practical and scalable solution for automating bin picking tasks, leading to enhanced efficiency, reduced costs, and improved safety in industrial and logistical processes.

In conclusion, this project demonstrates the successful development and implementation of a robust stereo vision-based system for robotic bin picking, paving the way for advancements in automation and grasp planning strategies in industrial and logistical processes.



Table of Contents

Contents

Introduction.....	5
Objective.....	6
Methodology.....	7
Sequence of Operations:	8
Vimba-based Dual Camera System for Real-Time Image Capture and Display:	8
Stereo Calibration – The Big Picture:	15
Observations	19
Stereo Rectification	20
Disparity	22
Stereo Vision Depth Estimation: An Interactive Exploration of Disparity Maps	31
Observations and Recordings	37
Conclusion.....	40
Appendix.....	41
Vimba Camera Setup	41
Stereo Calibration	45
Stereo Rectification	49
Disparity	51
Disparity GUI	57
References.....	62



Introduction

Bin picking, a persistent challenge in automation and robotics, necessitates innovative solutions due to the inherent variability of bin environments. Traditional approaches, often relying on meticulously controlled environments or specialized grippers, limit flexibility and adaptability to unstructured scenarios. Stereo vision, however, offers a promising alternative by mimicking human depth perception through images captured from slightly offset viewpoints. By analyzing the disparity between these images, stereo vision systems generate accurate 3D representations of bin contents, enabling robots to precisely perceive object location and orientation. This depth information is crucial for tasks like object recognition, pose estimation, and grasp planning.

This project explores the development and implementation of a stereo vision-based system for robotic bin picking, aiming to enhance efficiency and accuracy in real-world, unstructured environments.

By leveraging stereo vision's ability to provide detailed 3D information, the system enables robust object localization, precise pose estimation, and reliable grasp planning, overcoming the limitations of traditional approaches that struggle with object variability and occlusion. This work paves the way for advancements in automation and manipulation strategies in industries such as manufacturing, logistics, and e-commerce fulfillment, where the ability to efficiently handle objects in diverse configurations is paramount. The successful implementation of this system not only addresses a persistent challenge in robotics but also opens doors for further projects into more sophisticated object manipulation and autonomous decision-making in unstructured environments.



Objective

The overarching objective of this undertaking is to conceptualize and assess a robust stereo vision system capable of delivering precise three-dimensional reconstruction of objects within unstructured bin environments. Such environments encompass industrial parts bins, warehouse order picking bins, and recycling containers.

The realization of this vision entails the calibration of a stereo camera setup utilizing a chessboard pattern. Subsequently, corresponding points within captured images of the cluttered bin contents are identified and matched, culminating in the generation of accurate depth maps. The system endeavors to provide reliable three-dimensional object pose estimations, thus facilitating subsequent robotic tasks such as grasp planning and manipulation. This, in turn, enhances automation and efficiency within diverse industrial and logistical settings.



Methodology

The selection of software instruments is a pivotal element in any project, as it can have a significant impact on the expenses, ease of use, and long-term support of the project. In this study, a deliberate decision was made to utilize open-source tools and libraries for the development and evaluation of the stereo vision system. This decision was primarily driven by multiple key considerations.

Firstly, open-source tools and libraries offer substantial cost advantages. Unlike proprietary software, open-source tools are freely available and do not necessitate licensing fees, making them a cost-effective option for the project.

Secondly, open-source tools and libraries provide greater accessibility and flexibility. With open-source tools, researchers possess the freedom to modify and adapt the code to meet their specific needs and requirements. This flexibility helped to customize the tools and libraries to seamlessly integrate with the stereo vision system setup.

Thirdly, open-source tools and libraries frequently come with a large and active community of developers and users. This community provides valuable support, documentation, and troubleshooting resources. The research team benefited from this community support, as they were able to swiftly resolve technical issues and learn from the experiences of others who had employed the same tools and libraries.

Among the open-source tools and libraries employed in this study, Python 3.11 emerged as the primary development platform. Python is a versatile and widely utilized programming language that offers numerous advantages for scientific research. It is renowned for its simplicity of use, readability, and extensive library support.

The selection of Python was further supported by the availability of robust open-source libraries such as OpenCV, NumPy, and Matplotlib. OpenCV is a comprehensive library for computer vision and image processing, providing a broad range of functions for tasks such as feature detection, object tracking, and image manipulation. NumPy is a fundamental library for scientific computing, offering efficient data structures and functions for numerical operations. Matplotlib is a versatile library for data visualization, enabling the creation of various plots and charts.

In addition, the Vimba Viewer application was employed for its compatibility with the Allied Vision cameras utilized in this project, streamlining the image acquisition and camera control process. By utilizing these open-source tools, this project not only ensures accessibility and cost-effectiveness but also benefits from the continuous development and support provided by their dedicated communities.

Sequence of Operations:

- **Vimba-based Dual Camera System for Real-Time Image Capture and Display**

This Python script provides a robust solution for capturing, processing, and displaying real-time images from two Vimba-compatible cameras. The system is designed to be interactive, allowing users to save images on-demand, and features a software-triggered acquisition mechanism for consistent results.

The primary objectives of this script are:

- Real-Time Image Acquisition: Capture images simultaneously from two Vimba cameras in a continuous stream.
- Image Processing: Perform basic image processing operations, including:
 - Grayscale conversion for simplified analysis or reduced data size.
 - Resizing to a standard 640x480 resolution for display and consistency.
- Live Display: Present the captured images in separate windows for real-time monitoring and visual feedback.
- On-Demand Saving: Enable users to save individual image pairs to disk with a single key press.

Technical Overview

1. Camera Discovery and Initialization: The script identifies connected Vimba cameras using the vmbpy SDK, configures camera settings like auto-exposure (where available), and sets up a software trigger for image acquisition.
2. Error Handling: The script includes a check for the initial detection of cameras, it's beneficial to implement more comprehensive error handling for real-world scenarios.
3. Image Acquisition and Processing: The core functionality resides in the custom Handler class, which efficiently receives image frames from the cameras, converts them to the appropriate format, and queues them for display. The main loop of the script handles image resizing, grayscale conversion, and the display of images in separate windows labeled "Right Camera" and "Left Camera".
4. User Interaction: The script constantly monitors for user input. Pressing the 'Esc' key gracefully terminates the streaming process and closes the display windows, while pressing the 's' key triggers the saving of the current image frames from both cameras.

Libraries and Dependencies

- vmbpy (Vimba Python SDK): Essential for communication and control of Vimba-compatible machine vision cameras. Ensure that the Vimba SDK is installed and properly configured on your system.
- cv2 (OpenCV): A versatile computer vision library used for image processing, analysis, and display.

- numpy: A fundamental library for numerical operations, providing the foundation for efficient image manipulation within OpenCV.
- time, queue: Additional libraries used for time management and frame queuing to ensure smooth image streaming.

Installation and Configuration

1. Vimba SDK: Download and install the Vimba SDK from the official Allied Vision website (camera manufacturer's site). Follow the provided instructions for your specific operating system and camera model.
2. Python Libraries: Use the pip package manager to install the required Python libraries:
3. Camera Connection: Vimba cameras are properly connected to the computer via . Verify that the cameras are detected by the Vimba SDK.
4. Camera Settings: Consider manually adjusting the exposure settings within the script to optimize image quality for your specific lighting conditions. Refer to your camera's documentation for detailed instructions.

Usage :

1. The live camera feeds will be displayed in separate windows.
2. Press s to save the current image pair to disk.
3. Press Esc to exit the script.

Code Explanation:

The code Imports necessary libraries, including:

- `vmbpy` for Vimba camera access
- `cv2` (OpenCV) for image processing and display
- `numpy` for numerical operations
- Custom modules `Calibration`, `disparity`, and `disparityGUI2`

```
import cv2 as cv
import numpy as np
from vmbpy import *
import time
from queue import Queue
from typing import Optional
from typing import Callable
import matplotlib.pyplot as plt
import Calibration
import Disparity
import DISPARITY as disp
```

onMouse Function:

This function is designed to be a callback for mouse events on an image display.

Functionality:

- If the left mouse button is clicked (`cv.EVENT_LBUTTONDOWN`) on the image display of the disparity map, it will look up the disparity value `disparityNormalized[y][x]` at the clicked location. This value represents the estimated distance from the camera in centimeters to the 3D point corresponding to that pixel in the image.
- The disparity value is then printed to the console in the format "Distance in Centimeters: {distance}".

- Finally, the function returns the `distance` value.

```
def onMouse(event, x,y, flag, disparityNormalized):
    if event == cv.EVENT_LBUTTONDOWN:
        distance = disparityNormalized[y][x]
        print("Distance in Centimeters{}".format(distance))
    return distance
```

Camera Setup Functions (`get_camera`, `setup_camera`):

`get_camera()` Function:

- Uses a context manager (`with`) to ensure proper resource management with the Vimba system.
- Retrieves a list of all connected Vimba cameras using `vmb.get_all_cameras()`.
- Checks if any cameras are found. If not, it prints an error message and exits the script.
- Returns the list of discovered cameras.

`setup_camera(cam)` Function:

- Takes a `Camera` object as input.
- Uses a context manager (`with`) for the camera, ensuring proper setup and cleanup.
- Tries to set auto-exposure and auto-white balance to 'Continuous'. If these features aren't supported by the camera, it gracefully skips them.
- Tries to get the first stream (`stream = cam.get_stream()[0]`) and adjust the packet size for optimal data transmission using `stream.GVSPAdjustPacketSize.run()`. It waits until the adjustment is complete.

```

opencv_display_format = PixelFormat.Bgr8

def get_camera():
    with VmbSystem.get_instance() as vmb:
        cameras = vmb.get_all_cameras()
        if not cameras:
            print("No cameras Detected")
            exit()

    return cameras

def setup_camera(cam: Camera):
    with cam:

        try:
            cam.ExposureAuto.set('Continuous')
        except(AttributeError, VmbFeatureError):
            pass

        try:
            cam.BalanceWhiteAuto('Continuous')
        except(AttributeError, VmbFeatureError):
            pass
        try:
            stream = cam.get_stream()[0]
            stream.GVSPAdjustPacketSize.run()
            while not stream.GVSPAdjustPacketSize.is_done():
                pass
        except(AttributeError, VmbFeatureError):
            pass

```

Handler Class:

- Defines a custom class to handle incoming image frames from the cameras.
- `__init__`: Initializes a queue (`display_queue`) to hold up to 10 images.
- `get_image`: Provides a method to retrieve an image from the queue (blocking if the queue is empty).
- `__call__`: The main callback function executed when a new frame arrives.
 - Checks if the frame is complete.
 - If the frame format isn't already suitable for OpenCV, it converts it.
 - Adds the OpenCV-formatted image to the queue.
 - Re-queues the frame buffer to be reused for the next image.

```

class Handler:
    def __init__(self):
        self.display_queue = Queue(10)

    def get_image(self):
        return self.display_queue.get(True)

    def __call__(self, cam:Camera, stream:Stream, frame:Frame):
        if frame.get_status() == FrameStatus.Complete:
            print('{} acquired {}'.format(cam, frame), flush = True)

            if frame.get_pixel_format() == opencv_display_format:
                display = frame
            else:

                display = frame.convert_pixel_format(opencv_display_format)
                self.display_queue.put(display.as_opencv_image(), True)

            cam.queue_frame(frame)

```

triggerCamera and trigger Functions:

- `triggerCamera`: Configures the camera for software triggering.
- `trigger`: Sends a software trigger signal to the camera after a short delay (0.05 seconds).

```
def triggerCamera(camera):
    camera.TriggerSourceSet('Software')
    camera.TriggerModeSet('On')
    camera.TriggerSelector.set('FrameStart')
    camera.AcquisitionMode.set('continuous')

def trigger(camera):
    time.sleep(0.05)
    camera.TriggerSoftware.run()
```

Vimba System Context Manager:

- `with VmbSystem.get_instance() as vmb`: This line enters a context manager block using `VmbSystem.get_instance()`, which establishes a connection to the Vimba system. This is the entry point for interacting with Vimba-compatible cameras. The variable `vmb` is used to reference the Vimba system object within the block.

```
with VmbSystem.get_instance() as vmb:
    ## get access to the cameras
```

Camera Access and Setup:

- `with get_camera()[0] as camL, get_camera()[1] as camR`: This nested context manager block uses the `get_camera()` function (defined earlier) to retrieve the first two detected cameras and assigns them to the variables `camL` (left camera) and `camR` (right camera). The `with` statement ensures that the cameras are properly opened and closed.
- `setup_camera(camR), setup_camera(camL)`: Calls the `setup_camera` function for each camera to configure their settings (exposure, white balance, etc.).

```
img= None,
with get_camera() [0] as camL, get_camera() [1] as camR:

    ## setup cameras parameters
    setup_camera(camR)
    setup_camera(camL)
    triggerCamera(camL)
    triggerCamera(camR)
```

Image Handler Initialization:

- `handlerR = Handler(), handlerL = Handler()`: Creates instances of the custom `Handler` class for each camera. These handlers will be responsible for receiving image frames from the cameras and managing their processing and display.
- `blur = cv.GaussianBlur(img, (5, 5), 0)`: This applies a Gaussian blur to the image, for smoothening of the image.

```

handlerR = Handler()
handlerL = Handler()
blur = cv.GaussianBlur(img,(5,5),0) ## Gaussian blur for smoothness of the image
# manually setting off camerra exposure and Time set
camR.ExposureAuto.set('Off')
camR.ExposureTime.set('20000')
camL.ExposureAuto.set('Off')
camL.ExposureTime.set('20000')

try:
    camR.UseSetSelector.set('Default')
    camL.UseSetSelector.set('Default')
except(AttributeError, VmbFeatureError):
    print('Failed to load')
    try:

        camR.UseSetLoad.run()
        camL.UseSetLoad.run()
    except(AttributeError, VmbFeatureError):
        print('Failed to run the Features')

```

Video Streaming and Processing:

- `try...finally...`: A `try...finally` block is used to ensure that the cameras are always stopped gracefully, even if an error occurs during streaming.
- `camR.start_streaming(handler=handlerR, buffer_count=10)` and `camL.start_streaming(handler=handlerL, buffer_count=10)`: These lines initiate the continuous image streaming from both cameras. The `handler` argument specifies the `Handler` object that will receive the image frames. The `buffer_count` sets the number of frames that can be buffered before the camera stops acquiring new ones (to prevent memory issues).
- The `# (Main image acquisition, processing, and display loop)` comment indicates where the core image processing and display logic would be placed. This could involve:
 - Retrieving images from the `Handler` objects.
 - Converting images to grayscale.
 - Undistorting and rectifying images (if calibration data is available).
 - Calculating the disparity map using SGBM or other algorithms.
 - Displaying the images and/or disparity map in windows.

```

## video start streaming
try:
    camR.start_streaming(handler = handlerR, buffer_count = 10)
    camL.start_streaming(handler = handlerL, buffer_count = 10)

    msg = 'Stream from \'{\}\\. Press Esc key to stop stream'
    escKey = 27
    counter = 0
    size = (640,480)

    while True:

        ## get the image
        displayR = handlerR.get_image()
        displayL = handlerL.get_image()

        ##resize the image to 640x480
        imageR = cv.resize(displayR, size)
        imageL = cv.resize(displayL, size)

        grayR = cv.cvtColor(imageR, cv.COLOR_BGR2GRAY)
        grayL = cv.cvtColor(imageL, cv.COLOR_BGR2GRAY)
        cv.imshow('Right Camera'+ msg.format(camL.get_name()), grayR)
        cv.imshow('Left Camera' + msg.format(camL.get_name()), grayL)

        key = cv.waitKey(1)
        if key == escKey:
            cv.destroyWindow(msg.format(camR.get_name()))
            cv.destroyWindow(msg.format(camL.get_name()))
            camR.stop_streaming()
            camL.stop_streaming()
            cv.destroyAllWindows()
            break

        elif key == ord('s'):
            print('Images Saved!!!!')
            counter= counter+1
            cv.imwrite('S:\Bin Picking Project\TEST\ImgL_'+str(counter)+'.bmp',grayL)
            cv.imwrite('S:\Bin Picking Project\TEST\ImgR_'+str(counter)+'.bmp',grayR)

finally:
    camR.stop_streaming()
    camL.stop_streaming()

```

Stereo Calibration – The Big Picture

The goal of stereo calibration is to determine the precise relationship between the two cameras in the stereo vision setup. This relationship is crucial for accurately converting disparity maps (which represent the difference in pixel positions of the same object in the left and right images) into meaningful depth information.

Working:

1. Individual Camera Calibration (Intrinsic Parameters): Before calibrating the stereo system, you calibrate each camera individually. This involves finding the internal parameters of the camera, such as:
 - Focal Length: How strongly the lens converges or diverges light.
 - Principal Point: The center point where the optical axis intersects the image plane.
 - Distortion Coefficients: Parameters that model lens distortions (like barrel or pincushion distortion).
2. Stereo Calibration (Extrinsic Parameters): After calibrating the individual cameras, the stereo calibration process focuses on finding the extrinsic parameters of the stereo system:
 - Rotation Matrix: Describes how the right camera is rotated relative to the left camera.
 - Translation Vector: Indicates the distance between the two cameras along each axis (X, Y, and Z).

Code Explanation:

- A function named `StereoCalibration` that encapsulates the entire calibration process. This helps organize the code and makes it reusable if needed.

```
STERO CALIBRATION.py > StereoCalibration
import cv2 as cv
import numpy as np
import glob

def StereoCalibration():
```

This section sets up the parameters for chessboard corner detection:

- `boardsize`: Defines the number of internal corners on your calibration board.
- `framesize`: The resolution of your camera images.
- `criteria`: Sets the conditions for stopping the corner refinement process (maximum iterations or desired accuracy).
- `objp`: Calculates the 3D coordinates of the chessboard corners in the real world, assuming the board is on the Z=0 plane.
- The lists `objPoints`, `imgPointsL`, and `imgPointsR` will be used to store the detected corners across multiple images for both cameras.

```

##### FIND CHESSBOARD CORNERS #####
boardsize = (9,7)
framesize = (640,480)

# termination criteria
criteria = (cv.TERM_CRITERIA_EPS + cv.TERM_CRITERIA_MAX_ITER, 30, 0.001)

#prepare object points with numpy
objP = np.zeros((boardsize[0]*boardsize[1],3), np.float32)
objP[:, :2] = np.mgrid[0:boardsize[0],0:boardsize[1]].T.reshape(-1,2)

# Arrays to store object points and image points from all the images.
objPoints = [] # 3d point in real world space
imgPointsL = [] # 2d points in image plane of camera1.
imgPointsR = [] # 2d points in image plane of camera0.

```

Image Loading and Corner Finding:

- **glob.glob**: Finds all BMP image files in the specified directories for the left (CamL) and right (CamR) cameras.
- The **for** loop iterates through pairs of left and right images, loading them and finding the chessboard corners using **cv.findChessboardCorners**.
- If corners are found (**retL** and **retR** are **True**), the object points and refined image points are added to the respective lists.
- The corners are then drawn on the images and displayed for visual confirmation.

```

for imageL, imageR in zip(imagesL, imagesR):
    imgL = cv.imread(imageL)
    imgR = cv.imread(imageR)

    grayL = cv.cvtColor(imgL, cv.COLOR_BGR2GRAY)
    grayR = cv.cvtColor(imgR, cv.COLOR_BGR2GRAY)

    #find corners in the chessboard
    retL, cornersL = cv.findChessboardCorners(grayL, boardsize, None)
    retR, cornersR = cv.findChessboardCorners(grayR, boardsize, None)

    print(retL, retR)
    # If corners are found, add object points and image points
    if retL and retR == True:
        objPoints.append(objP)

        #append the chessboard corner point to imagepoints
        cornersL = cv.cornerSubPix(grayL, cornersL, (11,11), (-1,-1), criteria)
        imgPointsL.append(cornersL)
        cornersR = cv.cornerSubPix(grayR, cornersR, (11,11), (-1,-1), criteria)
        imgPointsR.append(cornersR)

    # draw and display the corners
    cv.drawChessboardCorners(imgL, boardsize,cornersL, retL)
    cv.imshow("LEFT_img", imgL)
    cv.drawChessboardCorners(imgR, boardsize,cornersR, retR)
    cv.imshow("RIGHT_img", imgR)

    cv.waitKey(3000)

cv.destroyAllWindows()

```

Camera Calibration:

- **cv.calibrateCamera**: Calibrates each camera individually using the collected object points and image points. This estimates the intrinsic parameters (camera matrix and distortion coefficients) for each camera.
- **cv.getOptimalNewCameraMatrix**: Calculates an improved camera matrix and a region of interest (ROI) to remove some distortion from the images.

```

#####
# CALIBRATION #####
#Camera1 Caliberation
calibrationL, cameraMatrixL, distortionL, rotVectorL, transVectorL = cv.calibrateCamera(objPointsL, imgPointsL, grayL.shape[::-1], None, None)
heightL, widthL, channelsL = imgL.shape
# # ##### Returns the new camera intrinsic matrix based on the free scaling parameter.
newCameraMatrixL, roi_L = cv.getOptimalNewCameraMatrix(cameraMatrixL, distortionL,(widthL, heightL), 1, (widthL, heightL))

# Camera2 Caliberation
calibrationR, cameraMatrixR, distortionR, rotVectorR, transVectorR = cv.calibrateCamera(objPointsR, imgPointsR, grayR.shape[::-1], None, None)
heightR, widthR, channelsR = imgR.shape
# # ##### Returns the new camera intrinsic matrix based on the free scaling parameter.
newCameraMatrixR, roi_R = cv.getOptimalNewCameraMatrix(cameraMatrixR, distortionR,(widthR, heightR), 1, (widthR, heightR))

```

Stereo Calibration:

- `cv.stereoCalibrate`: Calibrates the stereo camera system. It determines the relative rotation (`rotMatrix`) and translation (`transVector`) between the two cameras. This information is essential for stereo rectification and depth estimation.

Stereo Rectification:

- `cv.stereoRectify`: Computes the rectification transformations (`rectTransL`, `rectTransR`) that make the image planes of both cameras parallel. This is necessary for accurate disparity calculation.
 - `cv.initUndistortRectifyMap`: Creates maps for remapping pixels in the original images to the rectified space.

```
#####
# Stereo Rectification #####
# # Computes rectification transforms for each head of a calibrated stereo camera
# # # alpha = 1
# # # alpha=0 means that the rectified images are zoomed and shifted
rectifyScale = 1
rectTransL, rectTransR, projMatrixL, projMatrixR, disp2DepthMapMatrix, roiL, roiR = cv.stereoRectify(newCameraMatrixL, distCoeffsL, newCameraMat

stereoMapLx, stereoMapLy = cv.initUndistortRectifyMap(cameraMatrixL, distCoeffsL, rotMatrix, projMatrixL, grayL.shape[::-1], cv.CV_32FC1)
stereoMapRx, stereoMapRy = cv.initUndistortRectifyMap(cameraMatrixR, distCoeffsR, rotMatrix, projMatrixR, grayR.shape[::-1], cv.CV_32FC1)
```

Saving Calibration Parameters:

- Calibration results are saved to `.npy` files for individual parameters and a `.xml` file for the stereo maps. This allows you to reuse these parameters without recalibrating every time.

```

print("Saving Calibration Parameters")

np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\cameraMatrixLeft.npy', cameraMatrixL)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\cameraMatrixRight.npy', cameraMatrixR)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\newCameraMatrixLeft.npy', newCameraMatrixL)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\newCameraMatrixRight.npy', newCameraMatrixR)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\Distortion_CoefficientLeft.npy', distCoeffsL)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\Distortion_CoefficientRight.npy', distCoeffsR)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\RotationMatrixLR.npy', rotMatrix)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\TranslationVectorLR.npy', transVector)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\projectionMatrixLeft.npy', projMatrixL)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\projectionMatrixRight.npy', projMatrixR)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\rotationMatrixLeft.npy', rectL)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\rotationMatrixRight.npy', rectR)
np.save('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\disparity2depthMapMatrix.npy', disp2DepthMapMatrix)

print("saving Parameters")
cv_file = cv.FileStorage('S:\Bin Picking Project\TEST\pixel2wCos\calibParams\stereoMap.xml', cv.FILE_STORAGE_WRITE)

cv_file.write('stereoMapL_x', stereoMapLx)
cv_file.write('stereoMapL_y', stereoMapLy)
cv_file.write('stereoMapR_x', stereoMapRx)
cv_file.write('stereoMapR_y', stereoMapRy)

cv_file.release()

StereoCalibration()

```

OBSERVATIONS:




Fig. 1: Chessboard Corners Detection

```
opencv_storage
<stereoMap>
<type_id="opencv-matrix">
<rows>480</rows>
<cols>640</cols>
<dt>*2s</dt>
<data> 19 38 28 38 21 38 22 38 23 39 24 39 25 39 26 39 27 39 28 39 28 39 29 39 30 39 31 39 32 39 30 34 40 35 40 36 40 36 40 37 48 38 40 39 40 39 40 40 40 41 40 42 40 43 40 43 40 44 41
45 41 46 41 46 41 47 41 48 41 49 41 49 51 41 52 41 53 41 54 41 55 41 55 41 56 41 57 41 58 41 59 42 60 42 61 42 62 42 63 42 64 42 65 42 66 42 67 42 68 42 68 42
69 42 70 42 71 42 72 42 73 42 73 42 74 42 75 42 76 42 76 42 77 43 78 43 78 43 79 43 80 43 81 43 82 43 83 43 84 43 85 43 86 43 87 43 88 43 89 43 90 43 91 43 92 43
92 43 93 43 94 43 94 43 95 43 96 43 97 43 98 43 98 43 99 43 100 43 101 43 102 43 103 43 104 43 105 43 105 43 106 43 107 43 107 43 108 43 109 43 109 43 110 43 111 43 111 43 112 43
113 43 113 44 114 44 115 44 115 44 116 44 117 44 117 44 118 44 119 44 119 44 120 44 121 44 121 44 122 44 123 44 123 44 124 44 125 44 126 44 127 44 128 44 129 44 130 44 131 44 131
144 44 144 44 133 44 134 44 135 44 136 44 137 44 137 44 138 44 139 44 139 44 140 44 141 44 141 44 142 44 143 44 143 44 144 44 145 44 145 44 146 44 147 44 147 44 148 44 149 44 149 44 150 44
151 44 151 44 152 44 152 44 153 44 154 44 154 44 155 44 156 44 156 44 157 44 158 44 158 44 159 44 168 44 169 44 161 44 162 44 163 44 164 44 164 44 166 44 166 44 166 44 167 44 168 44 168 44 169
44 170 44 170 44 171 44 172 44 172 44 173 44 174 44 175 44 176 44 176 44 177 44 177 44 178 44 178 44 179 44 179 44 180 44 181 44 181 44 182 44 183 44 183 44 184 44 185 44 185 44 186 44 187 44 187 44
188 44 189 44 189 44 190 44 191 44 192 44 193 44 193 44 194 44 195 44 195 44 196 44 197 44 197 44 198 44 199 44 199 44 200 44 201 44 201 44 202 44 202 44 203 44 204 44 204 44 205 44 206 44 206
207 44 208 44 208 44 209 44 210 44 210 44 211 44 212 44 212 44 213 44 214 44 214 44 215 44 216 44 216 44 217 44 218 44 218 44 219 44 220 44 220 44 221 44 222 44 222 44 223 44 224 44 224 44 224 44 225 44
226 44 226 44 227 44 227 44 228 44 229 44 229 44 230 44 231 44 232 44 233 44 234 44 235 44 235 44 236 44 236 44 237 44 237 44 238 44 239 44 239 44 240 44 241 44 241 44 242 44 243 44 243 44 244
245 44 245 44 246 44 246 44 247 44 248 44 249 44 249 44 250 44 251 44 252 44 253 44 254 44 254 44 255 44 256 44 256 44 257 44 258 44 258 44 259 44 260 44 261 44 262 44 262 44
263 44 264 44 264 44 265 44 266 44 266 44 267 44 268 44 268 44 269 44 270 44 270 44 271 44 272 44 272 44 273 44 274 44 274 44 276 44 276 44 277 44 278 44 278 44 279 44 279 44 280 44 281 44 281
282 44 283 44 283 44 284 44 285 44 285 44 286 44 287 44 287 44 288 44 289 44 290 44 291 44 291 44 292 44 293 44 293 44 294 44 294 44 295 44 296 44 297 44 297 44 298 44 299 44 300 44
301 44 301 44 302 44 303 44 304 44 304 44 305 44 306 44 306 44 307 44 308 44 308 44 309 44 310 44 310 44 311 44 312 44 312 44 313 44 314 44 314 44 315 44 316 44 316 44 317 44 318 44 318 44 319
320 44 320 44 320 44 322 44 322 44 324 44 324 44 325 44 326 44 326 44 327 44 327 44 328 44 329 44 329 44 330 44 331 44 331 44 332 44 333 44 333 44 334 44 334 44 335 44 335 44 336 44 337 44 337 44
338 44 339 44 339 44 340 44 340 44 341 44 341 44 342 44 343 44 343 44 344 44 344 44 345 44 345 44 346 44 346 44 347 44 347 44 348 44 348 44 349 44 349 44 350 44 350 44 351 44 351 44 352 44 352 44 353 44 353 44 354 44 354 44 355 44 355 44 356 44 356 44 357 44 357 44 358 44 358 44 359 44 359 44 360 44 360 44 361 44 361 44 362 44 362 44 363 44 363 44 364 44 364 44 365 44 365 44 366 44 366 44 367 44 367 44 368 44 368 44 369 44 369 44 370 44 370 44 371 44 371 44 372 44 372 44 373 44 373 44 374 44 374 44
375 44 375 44 376 44 376 44 377 44 377 44 378 44 378 44 379 44 379 44 380 44 380 44 381 44 381 44 382 44 382 44 383 44 383 44 384 44 384 44 385 44 385 44 386 44 386 44 387 44 387 44 388 44 388 44 389 44 389 44 390 44 390 44 391 44 391 44 392 44 392 44 393 44 393 44 394 44 394 44 395 44 395 44 396 44 396 44 397 44 397 44 398 44 398 44 399 44 399 44 400 44 400 44 401 44 401 44 402 44 402 44 403 44 403 44 404 44 404 44 405 44 405 44 406 44 406 44 407 44 407 44 408 44 408 44 409 44 409 44 410 44 410 44 411 44 411 44 412 44 412 44 413 44 413 44 414 44 414 44 415 44 415 44 416 44 416 44 417 44 417 44 418 44 418 44 419 44 419 44 420 44 420 44 421 44 421 44 422 44 422 44 423 44 423 44 424 44 424 44 425 44 425 44 426 44 426 44 427 44 427 44 428 44 428 44 429 44 429 44 430 44 430 44 431 44 431 44 432 44 432 44 433 44 433 44 434 44 434 44 435 44 435 44 436 44 436 44 437 44 437 44 438 44 438 44 439 44 439 44 440 44 440 44 441 44 441 44 442 44 442 44 443 44 443 44 444 44 444 44 445 44 445 44 446 44 446 44 447 44 447 44 448 44 448 44 449 44 449 44 450 44 450 44 451 44 451 44 452 44 452 44 453 44 453 44 454 44 454 44 455 44 455 44 456 44 456 44 457 44 457 44 458 44 458 44 459 44 459 44 460 44 460 44 461 44 461 44 462 44 462 44 463 44 463 44 464 44 464 44 465 44 465 44 466 44 466 44 467 44 467 44 468 44 468 44 469 44 469 44 470 44 470 44 471 44 471 44 472 44 472 44 473 44 473 44 474 44 474 44 475 44 475 44 476 44 476 44 477 44 477 44 478 44 478 44 479 44 479 44 480 44 480 44 481 44 481 44 482 44 482 44 483 44 483 44 484 44 484 44 485 44 485 44 486 44 486 44 487 44 487 44 488 44 488 44 489 44 489 44 490 44 490 44 491 44 491 44 492 44 492 44 493 44 493 44 494 44 494 44 495 44 495 44 496 44 496 44 497 44 497 44 498 44 498 44 499 44 499 44 500 44 500 44 501 44 501 44 502 44 502 44 503 44 503 44 504 44 504 44 505 44 505 44 506 44 506 44 507 44 507 44 508 44 508 44 509 44 509 44 510 44 510 44 511 44 511 44 512 44 512 44 513 44 513 44 514 44 514 44 515 44 515 44 516 44 516 44 517 44 517 44 518 44 518 44 519 44 519 44 520 44 520 44 521 44 521 44 522 44 522 44 523 44 523 44 524 44 524 44 525 44 525 44 526 44 526 44 527 44 527 44 528 44 528 44 529 44 529 44 530 44 530 44 531 44 531 44 532 44 532 44 533 44 533 44 534 44 534 44 535 44 535 44 536 44 536 44 537 44 537 44 538 44 538 44 539 44 539 44 540 44 540 44 541 44 541 44 542 44 542 44 543 44 543 44 544 44 544 44 545 44 545 44 546 44 546 44 547 44 547 44 548 44 548 44 549 44 549 44 550 44 550 44 551 44 551 44 552 44 552 44 553 44 553 44 554 44 554 44 555 44 555 44 556 44 556 44 557 44 557 44 558 44 558 44 559 44 559 44 560 44 560 44 561 44 561 44 562 44 562 44 563 44 563 44 564 44 564 44 565 44 565 44 566 44 566 44 567 44 567 44 568 44 568 44 569 44 569 44 570 44 570 44 571 44 571 44 572 44 572 44 573 44 573 44 574 44 574 44 575 44 575 44 576 44 576 44 577 44 577 44 578 44 578 44 579 44 579 44 580 44 580 44 581 44 581 44 582 44 582 44 583 44 583 44 584 44 584 44 585 44 585 44 586 44 586 44 587 44 587 44 588 44 588 44 589 44 589 44 590 44 590 44 591 44 591 44 592 44 592 44 593 44 593 44 594 44 594 44 595 44 595 44 596 44 596 44 597 44 597 44 598 44 598 44 599 44 599 44 600 44 600 44 601 44 601 44 602 44 602 44 603 44 603 44 604 44 604 44 605 44 605 44 606 44 606 44 607 44 607 44 608 44 608 44 609 44 609 44 610 44 610 44 611 44 611 44 612 44 612 44 613 44 613 44 614 44 614 44 615 44 615 44 616 44 616 44 617 44 617 44 618 44 618 44 619 44 619 44 620 44 620 44 621 44 621 44 622 44 622 44 623 44 623 44 624 44 624 44 625 44 625 44 626 44 626 44 627 44 627 44 628 44 628 44 629 44 629 44 630 44 630 44 631 44 631 44 632 44 632 44 633 44 633 44 634 44 634 44 635 44 635 44 636 44 636 44 637 44 637 44 638 44 638 44 639 44 639 44 640 44 640 44 641 44 641 44 642 44 642 44 643 44 643 44 644 44 644 44 645 44 645 44 646 44 646 44 647 44 647 44 648 44 648 44 649 44 649 44 650 44 650 44 651 44 651 44 652 44 652 44 653 44 653 44 654 44 654 44 655 44 655 44 656 44 656 44 657 44 657 44 658 44 658 44 659 44 659 44 660 44 660 44 661 44 661 44 662 44 662 44 663 44 663 44 664 44 664 44 665 44 665 44 666 44 666 44 667 44 667 44 668 44 668 44 669 44 669 44 670 44 670 44 671 44 671 44 672 44 672 44 673 44 673 44 674 44 674 44 675 44 675 44 676 44 676 44 677 44 677 44 678 44 678 44 679 44 679 44 680 44 680 44 681 44 681 44 682 44 682 44 683 44 683 44 684 44 684 44 685 44 685 44 686 44 686 44 687 44 687 44 688 44 688 44 689 44 689 44 690 44 690 44 691 44 691 44 692 44 692 44 693 44 693 44 694 44 694 44 695 44 695 44 696 44 696 44 697 44 697 44 698 44 698 44 699 44 699 44 700 44 700 44 701 44 701 44 702 44 702 44 703 44 703 44 704 44 704 44 705 44 705 44 706 44 706 44 707 44 707 44 708 44 708 44 709 44 709 44 710 44 710 44 711 44 711 44 712 44 712 44 713 44 713 44 714 44 714 44 715 44 715 44 716 44 716 44 717 44 717 44 718 44 718 44 719 44 719 44 720 44 720 44 721 44 721 44 722 44 722 44 723 44 723 44 724 44 724 44 725 44 725 44 726 44 726 44 727 44 727 44 728 44 728 44 729 44 729 44 730 44 730 44 731 44 731 44 732 44 732 44 733 44 733 44 734 44 734 44 735 44 735 44 736 44 736 44 737 44 737 44 738 44 738 44 739 44 739 44 740 44 740 44 741 44 741 44 742 44 742 44 743 44 743 44 744 44 744 44 745 44 745 44 746 44 746 44 747 44 747 44 748 44 748 44 749 44 749 44 750 44 750 44 751 44 751 44 752 44 752 44 753 44 753 44 754 44 754 44 755 44 755 44 756 44 756 44 757 44 757 44 758 44 758 44 759 44 759 44 760 44 760 44 761 44 761 44 762 44 762 44 763 44 763 44 764 44 764 44 765 44 765 44 766 44 766 44 767 44 767 44 768 44 768 44 769 44 769 44 770 44 770 44 771 44 771 44 772 44 772 44 773 44 773 44 774 44 774 44 775 44 775 44 776 44 776 44 777 44 777 44 778 44 778 44 779 44 779 44 780 44 780 44 781 44 781 44 782 44 782 44 783 44 783 44 784 44 784 44 785 44 785 44 786 44 786 44 787 44 787 44 788 44 788 44 789 44 789 44 790 44 790 44 791 44 791 44 792 44 792 44 793 44 793 44 794 44 794 44 795 44 795 44 796 44 796 44 797 44 797 44 798 44 798 44 799 44 799 44 800 44 800 44 801 44 801 44 802 44 802 44 803 44 803 44 804 44 804 44 805 44 805 44 806 44 806 44 807 44 807 44 808 44 808 44 809 44 809 44 810 44 810 44 811 44 811 44 812 44 812 44 813 44 813 44 814 44 814 44 815 44 815 44 816 44 816 44 817 44 817 44 818 44 818 44 819 44 819 44 820 44 820 44 821 44 821 44 822 44 822 44 823 44 823 44 824 44 824 44 825 44 825 44 826 44 826 44 827 44 827 44 828 44 828 44 829 44 829 44 830 44 830 44 831 44 831 44 832 44 832 44 833 44 833 44 834 44 834 44 835 44 835 44 836 44 836 44 837 44 837 44 838 44 838 44 839 44 839 44 840 44 840 44 841 44 841 44 842 44 842 44 843 44 843 44 844 44 844 44 845 44 845 44 846 44 846 44 847 44 847 44 848 44 848 44 849 44 849 44 850 44 850 44 851 44 851 44 852 44 852 44 853 44 853 44 854 44 854 44 855 44 855 44 856 44 856 44 857 44 857 44 858 44 858 44 859 44 859 44 860 44 860 44 861 44 861 44 862 44 862 44 863 44 863 44 864 44 864 44 865 44 865 44 866 44 866 44 867 44 867 44 868 44 868 44 869 44 869 44 870 44 870 44 871 44 871 44 872 44 872 44 873 44 873 44 874 44 874 44 875 44 875 44 876 44 876 44 877 44 877 44 878 44 878 44 879 44 879 44 880 44 880 44 881 44 881 44 882 44 882 44 883 44 883 44 884 44 884 44 885 44 885 44 886 44 886 44 887 44 887 44 888 44 888 44 889 44 889 44 890 44 890 44 891 44 891 44 892 44 892 44 893 44 893 44 89
```

Stereo Rectification

This code is designed to load stereo calibration parameters (calculated earlier calibration script) and use them to perform two key operations:

1. **Undistortion:** Correcting lens distortion present in the raw images from the left and right cameras.
2. **Rectification:** Transforming the undistorted images so that corresponding points lie on the same horizontal line (as explained earlier).

Breakdown of Functions:

- **`undistort(image0, image1):`**
 - **Input:** Takes the raw (distorted) images from the left (`image0`) and right (`image1`) cameras.
 - **Process:** Loads camera matrices (`camMatrix0, camMatrix1`) and distortion coefficients (`distcoef0, distcoef1`) from the saved calibration files.
Also loads the optimal new camera matrices (`newCamMat0, newCamMat1`), which might be slightly adjusted from the original ones to minimize unwanted pixels after undistortion.
Applies OpenCV's `cv.undistort` function to each image, using the corresponding camera matrix and distortion coefficients.
 - **Output:** Returns the undistorted versions of the left and right images.
- **`undistortRectify(imageL, imageR):`**
Input: Takes the undistorted images from the left (`imageL`) and right (`imageR`) cameras.
Process: Loads additional calibration parameters:
 - Rectification transformation matrices (`rectTransL, rectTransR`)
 - Projection matrices (`projMatrixL, projMatrixR`)**Active :** Re-computes the stereo maps using `cv.initUndistortRectifyMap` for each camera. This step combines undistortion and rectification into a single transformation.
Applies the stereo maps using `cv.remap` to rectify (and undistort, if not done before) both images.
Output: Returns the rectified (and undistorted) versions of the left and right images, where corresponding points are now aligned on the same row.
- **Workflow:**
 1. **Stereo Calibration:** You first run the calibration script you provided earlier to calculate and save all the necessary parameters.
 2. **Load Parameters:** This new code snippet loads those saved parameters.
 3. **Undistort and Rectify:** You then use these functions on pairs of stereo images:
 - Call `undistort` on the raw images.

- Call `undistortRectify` on the undistorted images (or directly on the raw images if you're recomputing the maps).
4. **Stereo Matching:** Now you have rectified images that are ready for stereo matching algorithms (like block matching or semi-global block matching) to compute disparity maps and ultimately depth information.

Key Points:

- **Flexibility:** The code provides two ways to handle rectification: using pre-computed maps for speed or recomputing them on-the-fly for flexibility.
- **Dependency:** This code relies entirely on the calibration parameters obtained from the first script.
- **Purpose:** This step is essential for most stereo vision applications, as rectified images greatly simplify the task of finding corresponding points, leading to more accurate depth estimation.

```
> Bin Picking Project > TEST > stereoVision > Calibration.py > ...
1 import sys
2 import cv2 as cv
3 import numpy as np
4
5 ## Load the Parameters
6 camMatrix0 = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\cameraMatrixLeft.npy')
7 camMatrix1 = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\cameraMatrixRight.npy')
8 distcoef0 = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\Distortion_CoefficientLeft.npy')
9 distcoef1 = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\Distortion_CoefficientRight.npy')
10 newCamMat0 = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\newcameraMatrixLeft.npy')
11 newCamMat1 = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\newcameraMatrixRight.npy')
12 rectTransL = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\rotationMatrixLeft.npy')
13 rectTransR = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\calibParams\rotationMatrixRight.npy')
14 projMatrixL = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\projectionMatrixLeft.npy')
15 projMatrixR = np.load('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\projectionMatrixRight.npy')
16
17
18 def undistort(image0, image1):
19
20
21     #The function is simply a combination of initUndistortRectifyMap (with unity R ) and remap (with bilinear interpolation)
22     undistorted0 = cv.undistort(image0, camMatrix0, distcoef0, newCamMat0)
23     undistorted1 = cv.undistort(image1, camMatrix1, distcoef1, newCamMat1)
24
25     return undistorted0, undistorted1
26
27
28 def undistortRectify(imageL, imageR):
29
30     ## Load the parameters
31     cv_file = cv.FileStorage()
32     ## cv_file.open('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/stereoMap.xml', cv.FileStorage_READ)
33     ## stereoMapL_x = cv_file.getNode('stereoMapL_x').mat()
34     ## stereoMapL_y = cv_file.getNode('stereoMapL_y').mat()
35     ## stereoMapR_x = cv_file.getNode('stereoMapR_x').mat()
36     ## stereoMapR_y = cv_file.getNode('stereoMapR_y').mat()
```

Disparity:

Disparity is a fundamental concept in stereo vision, referring to the difference in image coordinates of a point between the left and right camera views. This difference arises due to the horizontal separation (baseline) between the two cameras. By analyzing the disparity values in a pair of rectified stereo images, we can compute a disparity map, which is a representation of the scene's depth information. Larger disparities indicate closer objects, while smaller disparities correspond to objects farther away from the camera. Disparity estimation is crucial for tasks like 3D reconstruction, depth sensing, and obstacle detection in applications such as autonomous navigation, robotics, and augmented reality.

Code Explanation:

Import Libraries: Import the necessary libraries for image processing (OpenCV), numerical calculations (NumPy), file management (glob, sys), and visualization (Matplotlib).

```
import cv2 as cv
import numpy as np
import glob
import sys
import matplotlib.pyplot as plt
```

Calibration Parameters:

- **boardSize**: Define the dimensions of the checkerboard pattern used for calibration. This should match your physical checkerboard.
- **frameSize**: Set the resolution of the camera images.
- **criteria**: Termination criteria for the corner refinement algorithm (`cv2.cornerSubPix`). The algorithm stops iterating when either the specified accuracy (`0.001`) is reached or the maximum number of iterations (`30`) is exceeded.

```
# Calibration Parameters (Modify as per your setup)
boardSize = (7, 9) # Number of inner corners on the chessboard (horizontal, vertical)
frameSize = (640, 480) # Resolution (width, height) of the camera images
criteria = (cv.TERM_CRITERIA_EPS + cv.TERM_CRITERIA_MAX_ITER, 30, 0.001) # Stopping criteria for calibration accuracy
```

Object Points (3D):

- **objp**: Creates a 3D array to store the coordinates of the checkerboard corners in real-world space. Since we know the dimensions of the checkerboard and assume it's flat, we set the Z-coordinate of all corners to 0.
- **np.mgrid**: Generates a 2D grid of coordinates for the checkerboard corners in the X-Y plane.
- **T.reshape**: Reshapes the coordinates into a format suitable for the calibration function.
- Initialize empty lists to store the object points (3D) and image points (2D) detected in the calibration images.

```
# Prepare 3D Object Points (Chessboard Corners in Real-World Coordinates)
objp = np.zeros((boardSize[0] * boardSize[1], 3), np.float32) # Create an array for object points
objp[:, :2] = np.mgrid[0:boardSize[0], 0:boardSize[1]].T.reshape(-1, 2) # Fill the array with corner coordinates

# Arrays to Store Points from Calibration Images
objPoints = [] # 3D points in real world space
imgPointsL = [] # 2D points in left image plane
imgPointsR = [] # 2D points in right image plane
```

calibrate_camera Function:

- This function takes a list of calibration image paths, the checkerboard size, frame size, and termination criteria as input.
- For each image:
 - Loads the image using `cv2.imread`.
 - Converts it to grayscale using `cv2.cvtColor`.
 - Finds the checkerboard corners using `cv2.findChessboardCorners`.
 - If corners are found, the object points (`objp`) and the refined corner locations (`corners2`) are added to their respective lists.
 - The checkerboard corners are drawn on the image using `cv2.drawChessboardCorners` for visual confirmation.
- Finally, it uses `cv2.calibrateCamera` to calculate the intrinsic camera parameters (camera matrix and distortion coefficients) based on the collected object and image points.

```
# --- Function to Calibrate the Camera ---
def calibrate_camera(images, boardSize, frameSize, criteria):
    objpoints = []
    imgpoints = []

    for image in images:
        img = cv.imread(image)
        gray = cv.cvtColor(img, cv.COLOR_BGR2GRAY)

        # Find the chess board corners
        ret, corners = cv.findChessboardCorners(gray, boardSize, None)

        # If found, add object points, image points (after refining them)
        if ret:
            objpoints.append(objp)

            corners2 = cv.cornerSubPix(gray, corners, (11, 11), (-1, -1), criteria)
            imgpoints.append(corners2)

            # Draw and display the corners
            img = cv.drawChessboardCorners(img, boardSize, corners2, ret)
            cv.imshow('img', img)
            cv.waitKey(500)

    cv.destroyAllWindows()
    ret, mtx, dist, rvecs, tvecs = cv.calibrateCamera(objpoints, imgpoints, frameSize, None, None)
    return ret, mtx, dist, rvecs, tvecs
```

depth_map Function:

- This function calculates the disparity and depth map from rectified stereo images (`imgL` and `imgR`).
- It takes the stereo rectification maps (`leftMapX`, `leftMapY`, `rightMapX`, `rightMapY`) and the disparity-to-depth mapping matrix (`Q`) as input from the calibration.
- It uses the Semi-Global Block Matching (SGBM) algorithm (`cv2.StereoSGBM_create`) to compute the disparity map as it's a popular algorithm for calculating disparity maps in stereo vision. It strikes a balance between accuracy and computational efficiency, making it suitable for real-time applications.
working of SGBM algorithm:

1. Matching Cost Computation:

- The algorithm divides the input images into small blocks (e.g., 3x3 pixels in this code).
- For each block in the left image, it compares it to candidate blocks in the right image, calculating a matching cost for each potential correspondence.
- The matching cost measures how similar the two blocks are (e.g., using the Sum of Absolute Differences – SAD).

2. Cost Aggregation:

- SGBM aggregates the matching costs along multiple paths (typically 8 or 16 directions) for each pixel. This "semi-global" aggregation helps to improve the accuracy and robustness of the disparity estimates, reducing noise and smoothing out discontinuities.
- The aggregation step considers both the local matching costs and smoothness constraints to find the optimal disparity for each pixel.

3. Disparity Optimization:

- After aggregation, the algorithm finds the disparity value with the lowest aggregated cost for each pixel. This is the final disparity estimate, representing the horizontal shift between the corresponding points in the left and right images.
- Additional post-processing steps, such as subpixel interpolation and outlier removal, can be applied to further refine the disparity map.

SGBM Parameters in the Code

1. `minDisparity`: The minimum possible disparity value (negative values allow for objects closer to the camera than the plane of focus).
2. `numDisparities`: The number of disparity levels to consider. A higher value increases the maximum measurable depth but also increases computational complexity.
3. `blockSize`: The size of the blocks used for matching. Larger blocks may be more robust to noise but may also lose finer details.
4. `P1`, `P2`: Penalty parameters for disparity changes between neighboring pixels. They control the smoothness of the disparity map.

5. **disp12MaxDiff**: This parameter controls the maximum allowed difference in disparity values between corresponding pixels in the left and right images that are 12 pixels apart in the scanline. Setting it to a higher value allows for more flexibility in handling areas with repetitive patterns or textureless regions, but it may also introduce more noise in the disparity map. A value of -1 disables this check, which is the default in OpenCV.
6. **uniquenessRatio**: This parameter influences the uniqueness of the selected matches during cost aggregation. A higher value enforces stricter uniqueness, meaning that a pixel in the left image is less likely to be matched to multiple pixels in the right image. This can reduce the number of false matches, especially in low-texture areas, but it might also lead to some valid matches being rejected.
7. **speckleWindowSize**: This parameter defines the size of a region used for speckle filtering. Speckle filtering aims to remove small, isolated regions in the disparity map that are likely caused by noise or mismatches. A larger window size removes larger speckles, but it might also smooth out legitimate details in the scene.
8. **speckleRange**: This parameter sets the maximum allowed disparity variation within a speckle region. If the disparity variation within a region exceeds this value, the region is considered a speckle and is removed. A higher value allows for more disparity variation within a region, potentially preserving more details, but it also increases the risk of preserving noise.
9. **preFilterCap**: This parameter limits the range of intensity values in the pre-filtering step of SGBM. It helps to reduce noise and improve the accuracy of the matching cost computation, especially in images with high dynamic range.
10. **mode**: This parameter selects the SGBM mode, determining the specific algorithm variant to be used.
 - **cv.STEREO_SGBM_MODE_SGBM**: The standard SGBM mode.
 - **cv.STEREO_SGBM_MODE_HH**: A mode that emphasizes horizontal smoothness (used for images with significant horizontal structures).
 - **cv.STEREO_SGBM_MODE_SGBM_3WAY**: This mode computes three disparity maps (using different penalty parameters) and averages them, potentially improving accuracy in some cases (this is the mode used in your code).

```
# --- Function to Calculate Depth Map from Stereo Images ---
def depth_map(imgL, imgR, Q, leftMapX, leftMapY, rightMapX, rightMapY):
    window_size = 3 # SGBM Parameters

    left_matcher = cv.StereoSGBM_create(
        minDisparity=-1,
        numDisparities=5*16,
        blockSize=window_size,
        P1=8 * 3 * window_size,
        P2=32 * 3 * window_size,
        disp12MaxDiff=12,
        uniquenessRatio=10,
        speckleWindowSize=50,
        speckleRange=32,
        preFilterCap=63,
        mode=cv.STEREO_SGBM_MODE_SGBM_3WAY
    )
```

```
right_matcher = cv.ximgproc.createRightMatcher(left_matcher)
```

- **Purpose:** In stereo vision, the left and right matchers are used to compute disparity maps for both images independently. While the `left_matcher` calculates disparity values for the left image (how much each pixel in the left image is shifted to the right compared to its corresponding pixel in the right image), the `right_matcher` does the opposite – it calculates the disparity for the right image (how much each pixel is shifted to the left compared to its corresponding pixel in the left image).
- `cv.ximgproc.createRightMatcher(left_matcher)`: This OpenCV function creates a right matcher that is specifically designed to be compatible with the given `left_matcher`. The matching costs and parameters of the right matcher are automatically configured to mirror those of the left matcher, ensuring consistency in the disparity calculations.

Need of two matchers:-

Using two matchers provides a form of cross-checking to improve the quality of the disparity map. The disparity values obtained from both matchers can be compared and combined to identify and correct errors. For example, if the left matcher finds a disparity of 5 for a pixel, but the right matcher finds a disparity of -3 for the same pixel, it's likely that one of these values is incorrect. The WLS filter, which is applied later, leverages the information from both matchers to refine the disparity estimates.

lmbda = 80000 (Lambda)

- **Purpose:** This parameter (`lambda`) is used by the Weighted Least Squares (WLS) filter. The WLS filter aims to smooth out the disparity map while preserving object boundaries. Lambda controls the relative weight given to the data term (the raw disparity values) versus the smoothness term (how much neighboring disparities should influence each other).
- **Effect of High Lambda:** A higher lambda value like 80000 emphasizes smoothness, leading to a smoother disparity map but potentially over-smoothing some fine details. This can be beneficial for reducing noise, especially in low-texture regions.

sigma = 1.3 (Sigma)

- **Purpose:** This parameter (`sigma`) is also used by the WLS filter. It controls the sensitivity of the filter to color differences between pixels. A larger sigma value means that the filter is less sensitive to color differences, leading to more aggressive smoothing.
- **Effect of Low Sigma:** A smaller sigma value like 1.3 makes the filter more sensitive to color changes, allowing it to preserve edges and object boundaries more effectively during the smoothing process.

```
right_matcher = cv.ximgproc.createRightMatcher(left_matcher)
lmbda = 80000
sigma = 1.3
```

Image Rectification:

- Purpose:** The `cv2.remap` function is used to rectify the left (`imgL`) and right (`imgR`) stereo images. Rectification is a geometric transformation that warps the images so that corresponding points (points representing the same 3D object in the scene) appear on the same horizontal line in both images. This simplifies the subsequent disparity calculation step.

Inputs:

- `imgL, imgR`: The original left and right stereo images.
- `leftMapX, leftMapY, rightMapX, rightMapY`: These are mapping matrices obtained from the stereo rectification process (`cv2.stereoRectify`). They define the pixel transformations required to warp the images.

Output:

- `imgL, imgR`: The rectified left and right images.

Interpolation: `cv2.INTER_LINEAR` indicates that linear interpolation should be used to fill in the values of pixels that fall between integer coordinates after the remapping process.

```
# Rectify Images
imgL = cv.remap(imgL, leftMapX, leftMapY, cv.INTER_LINEAR)
imgR = cv.remap(imgR, rightMapX, rightMapY, cv.INTER_LINEAR)
```

Disparity Calculation:

- Purpose:** This step computes the disparity map, which encodes the horizontal displacement between corresponding points in the rectified left and right images. Disparity is directly related to depth—larger disparities correspond to closer objects.

`left_matcher.compute(imgL, imgR):`

- `left_matcher`: This is an instance of the Semi-Global Block Matching (SGBM) algorithm (`cv2.StereoSGBM_create`) that has been configured earlier in the code.
- This line performs the actual disparity calculation using the SGBM algorithm on the rectified images.

Output:

- **Disparity map**: 16-bit image showing horizontal shift of each pixel.

```
# Disparity Calculation and Filtering
disparity = left_matcher.compute(imgL, imgR)
disparity = np.int16(disparity)
filteredImg = wls_filter.filter(disparity, imgL, None, None)
```

- Code applies a Weighted Least Squares (WLS) filter
`cv2.ximgproc.createDisparityWLSFilter()`: Creates a WLS filter object.
`wls_filter.filter(disparity, imgL, None, None)`: Applies the WLS filter to the raw disparity map, using the left image as a reference to preserve object boundaries. This filtering step further improves the accuracy of the disparity estimates.
- Finally, it uses the `Q` matrix to reproject the disparity map into 3D points (`cv2.reprojectImageTo3D`) to obtain a depth map then the disparity map is normalized and converted to a uint8 format for visualization.

```
# Convert to Depth Map
points_3D = cv.reprojectImageTo3D(filteredImg, Q)
```

Main Program:

- Check Arguments: The code first ensures that the user has provided the correct command-line arguments when running the script. It expects two arguments: the file path for the left image and the file path for the right image. If the arguments are missing, it prints a usage message and exits.

```
# --- Main Program ---
if __name__ == "__main__":
    # Check if image paths were provided as arguments
    if len(sys.argv) < 3:
        print("Usage: python your_script.py <left_image_path> <right_image_path>")
        sys.exit(1)

    left_image_path = sys.argv[1]
    right_image_path = sys.argv[2]
```

Load Stereo Images:

- It loads the right and left images using `cv2.imread`. The `imageSize` variable stores the dimensions (height and width) of the left image, which should be the same as the right image since they are a stereo pair.

```
# Load and Preprocess Images (After Calibration)
imagesR = cv.imread(right_image_path)
imagesL = cv.imread(left_image_path)

if imagesR is None or imagesL is None:
    raise ValueError("Error loading images. Check file paths and ensure images are valid.")

imageSize = imagesL.shape[:2]
```

Load Calibration Images:

- It uses `glob.glob` to find all the calibration images for both the left (`CamL`) and right (`CamR`) cameras, which are saved as `.bmp` files in the specified directories.

```
# Load Images (For Both Cameras)
imagesL_cali = glob.glob(r"D:\Bin Picking Project\3\Cam1\*.bmp")
imagesR_cali = glob.glob(r"D:\Bin Picking Project\3\Cam0\*.bmp")
```

Camera Calibration:

- It calls the `calibrate_camera` function twice (once for each camera) to determine the intrinsic camera parameters (camera matrices and distortion coefficients) using the loaded calibration images.

```
# Camera Calibration
retL, mtxL, distL, rvecsL, tvecsL = calibrate_camera(imagesL_cali, boardSize, frameSize, criteria)
retR, mtxR, distR, rvecsR, tvecsR = calibrate_camera(imagesR_cali, boardSize, frameSize, criteria)
```

Calibration Check:

- Verifies that at least two valid calibration images were found for each camera. If not, it displays an error message and exits.

```
# Check if there are enough points for calibration
if len(objPoints) < 2:
    print("Not enough calibration images found. Please use at least 2 images.")
    exit()
```

Stereo Calibration:

- Performs stereo calibration using `cv2.stereoCalibrate` with fixed intrinsic parameters to find the relative rotation and translation between the cameras.
- `cv2.stereoCalibrate` is used to find the relative rotation (`R`) and translation (`T`) between the two cameras, along with other parameters like the essential matrix (`E`) and fundamental matrix (`F`).
- It checks if the stereo calibration was successful, raising an error if it failed.

```
# Stereo Calibration
flags = 0
flags |= cv.CALIB_FIX_INTRINSIC
criteria_stereo = (cv.TERM_CRITERIA_EPS + cv.TERM_CRITERIA_MAX_ITER, 30, 0.001)

retS, newCameraMatrixL, distCoeffsL, newCameraMatrixR, distCoeffsR, R, T, E, F = cv.stereoCalibrate(
    objPoints, imgPointsL, imgPointsR, mtxL, distL, mtxR, distR,
    imageSize, criteria_stereo, flags
)
if not retS:
    raise ValueError("Stereo calibration failed. Check your calibration images and settings.")
```

Stereo Rectification:

- `cv2.stereoRectify` computes rectification transforms to correct lens distortion and align the stereo images for disparity calculation.
- `cv2.initUndistortRectifyMap` generates mapping matrices (`left_map1`, `left_map2`, etc.) for remapping the images during rectification.

```
# Stereo Rectification
rectify_scale = 1
R1, R2, P1, P2, Q, validPixROI1, validPixROI2 = cv.stereoRectify(
    newCameraMatrixL, distCoeffsL, newCameraMatrixR, distCoeffsR,
    imageSize, R, T, rectify_scale, (0, 0)
)
left_map1, left_map2 = cv.initUndistortRectifyMap(newCameraMatrixL, distCoeffsL, R1, P1, imageSize, cv.CV_16SC2)
right_map1, right_map2 = cv.initUndistortRectifyMap(newCameraMatrixR, distCoeffsR, R2, P2, imageSize, cv.CV_16SC2)
```

Disparity and Depth Calculation:

- Calls the `depth_map` function to compute the disparity map and the 3D points using the rectified images and the `Q` matrix.

```
# Calculate Disparity and Depth Map (Pass rectification maps)
disparity, points_3D = depth_map(imagesL, imagesR, Q, left_map1, left_map2, right_map1, right_map2)
```

Display Disparity Map:

- Visualizes the calculated disparity map using Matplotlib. Brighter areas in the map represent objects closer to the camera, while darker areas represent objects farther away.

```
# Visualization
plt.imshow(disparity, 'gray')
plt.title('Disparity Map')
plt.show()
```

Stereo Vision Depth Estimation: An Interactive Exploration of Disparity Maps

This graphical user interface (GUI) allows users to interactively explore the process of depth estimation in stereo vision. By adjusting parameters of the Semi-Global Block Matching (SGBM) algorithm, users can observe the resulting disparity map, a visual representation of depth information, in real-time. This tool provides a hands-on way to understand how different parameters affect the accuracy and quality of depth estimation, making it valuable for both educational and research purposes in fields such as robotics, autonomous navigation, and 3D reconstruction.

Key Features and Functionality

- **Intuitive Interface:** The GUI presents an intuitive interface with sliders for adjusting various parameters of the Semi-Global Block Matching (SGBM) algorithm, a widely used method for disparity estimation.
- **Real-Time Updates:** The disparity map is dynamically updated as the user adjusts parameters, providing immediate visual feedback on how different settings affect depth perception.
- **Color-Coded Visualization:** The disparity map is displayed using a vibrant JET colormap, where closer objects are represented in blue and farther objects in red, aiding in the interpretation of depth information.
- **Disparity Value Display:** Users can click on any point within the disparity map to view the precise disparity value at that location, aiding in the analysis and validation of results.
- **Parameter Sliders:** The GUI offers sliders for adjusting the following SGBM parameters:
 - `blockSize`: Size of the blocks used for matching.
 - `preFilterCap`: Intensity threshold for pre-filtering.
 - `minDisparity`: Minimum possible disparity value.
 - `numDisparities`: Number of disparity levels considered.
 - `preFilterSize`: Size of the pre-filtering kernel.
 - `textureThreshold`: Texture threshold for disparity computation.
 - `uniquenessRatio`: Enforces the uniqueness of matches.
 - `speckleRange`: Maximum disparity variation within a speckle.
 - `speckleWindowSize`: Size of the speckle filter window.
 - `P1, P2`: Penalty parameters for disparity change.
 - `disp12MaxDiff`: Maximum allowed difference in disparity for pixels 12 pixels apart.

Code Explanation:

1. Import Libraries:

- `tkinter` (aliased as `tk`): Provides the foundation for creating the graphical user interface (GUI) elements like windows, sliders, and canvases.
- `cv2` (OpenCV): Used for image loading, disparity calculation, and some visualization tasks.

- `numpy` (as `np`): Enables efficient numerical operations on the disparity map data.
- `PIL` (Python Imaging Library): Allows loading and manipulation of images in various formats.
- `ImageTk`: A module from PIL that bridges the gap between PIL images and Tkinter for display in GUI components.

```
import tkinter as tk
import cv2
import numpy as np
from PIL import Image, ImageTk
```

2. Load Stereo Images:

- Attempts to load the left and right stereo images in grayscale format.
- The `try-except` block handles potential errors during image loading, providing an error message and exiting the program if the images cannot be loaded.

```
# Load stereo images (BMP format)
try:
    left_image = cv2.imread("ImageL_1.bmp", cv2.IMREAD_GRAYSCALE)
    right_image = cv2.imread("ImageR_1.bmp", cv2.IMREAD_GRAYSCALE)
except Exception as e:
    print(f"Error loading images: {e}")
    exit() # Exit the program if images can't be loaded
```

3. Check Image Loading:

- Verifies that both images were successfully loaded. If either image is missing, an error message is printed and the program exits.

```
# Check if images were loaded successfully
if left_image is None or right_image is None:
    print("Error: Could not load one or both of the images.")
    exit()
```

4. Initialize Disparity Variables:

- `disparity`: Will store the raw disparity map (16-bit signed integers) calculated by the SGBM algorithm.
- `disparity_color`: Will store the colorized version of the disparity map for display.

```
# Initialize variables for disparity maps
disparity = None
disparity_color = None
```

5. Create SGBM Object:

- Creates an instance of the OpenCV StereoSGBM class to handle disparity calculation using the SGBM algorithm.
- `mode=3` specifies the use of the `STEREO_SGBM_MODE_SGBM_3WAY` mode, which computes three disparity maps with different parameters and averages them for potentially improved accuracy.

```
# Create StereoSGBM object for disparity calculation (SGBM_3WAY mode)
stereo = cv2.StereoSGBM_create(mode=3)
```

6. Mouse Callback Function:

- `on_mouse`: This function is executed whenever the user clicks the left mouse button on the disparity map canvas.
- It checks if the click is within the valid bounds of the disparity image.
- It retrieves the disparity value at the clicked pixel, divides it by 16 to scale it to the correct units, and updates the `disparity_label` in the GUI to display the value.

```
# Mouse callback function to display disparity value at clicked point
def on_mouse(event, x, y, flags, param):
    global disparity
    if event == cv2.EVENT_LBUTTONDOWN and disparity is not None:
        # Check if click is within image bounds
        if 0 <= y < disparity.shape[0] and 0 <= x < disparity.shape[1]:
            # Disparity values are scaled by 16, so divide by 16 for actual value
            disparity_value = disparity[y, x] / 16.0
            if disparity_value > 0: # Ensure valid disparity (positive)
                disparity_label.config(text=f"Disparity: {disparity_value:.2f}")
```

7. Update Disparity Function:

- This function is called whenever any of the slider values change.
- It reads the current values from all sliders and updates the parameters of the `stereo` (SGBM) object accordingly.
- It recalculates the disparity map using the updated parameters (`stereo.compute`).
- It normalizes the disparity map to a range of 0-255.
- It applies the JET colormap to the normalized disparity map.
- It converts the colored disparity map to a PIL `Image` and then to an `ImageTk.PhotoImage` for display in Tkinter.
- It updates the disparity canvas to show the new disparity image.

```

# Set parameters for StereoSGBM algorithm
stereo.setBlockSize(block_size)
stereo.setPreFilterCap(preFilterCap_slider.get())
stereo.setMinDisparity(minDisparity_slider.get())
stereo.setNumDisparities(numDisparities_slider.get())
textureThreshold = textureThreshold_slider.get()
uniquenessRatio = uniquenessRatio_slider.get()
speckleRange = speckleRange_slider.get()
speckleWindowSize = speckleWindowSize_slider.get()
P1 = P1_slider.get()
P2 = P2_slider.get()
disp12MaxDiff = disp12MaxDiff_slider.get()

# Compute disparity map
disparity = stereo.compute(left_image, right_image)

# Normalize disparity for color mapping and display (0-255)
disparity_normalized = cv2.normalize(disparity, None, 0, 255, cv2.NORM_MINMAX, cv2.CV_8UC1)

# Apply JET colormap to the normalized disparity
disparity_color = cv2.applyColorMap(disparity_normalized, cv2.COLORMAP_JET)

# Convert disparity maps to PIL Image for display
disparity_image = Image.fromarray(disparity_color) # Use color map here
disparity_photo = ImageTk.PhotoImage(disparity_image)

# Update canvas with new disparity image
disparity_canvas.config(width=disparity_image.width, height=disparity_image.height)
disparity_canvas.delete("all")
disparity_canvas.create_image(0, 0, anchor=tk.NW, image=disparity_photo)
# Store reference to avoid garbage collection of the image
disparity_canvas.image = disparity_photo
disparity_canvas.bind("<Button-1>", on_mouse) # Bind mouse events for value display

```

8. GUI Setup:

- This section creates the main application window using `tk.Tk()` and sets its title to "Disparity Map GUI".
- A frame (`slider_frame`) is created to hold all the parameter sliders. It is placed on the left side of the window using the grid layout manager.

9. Create Sliders:

- A `create_slider` function is defined to simplify the creation of sliders. It takes the slider label, range, resolution, default value (optional), and length as input and returns a `tk.Scale` object.
- Multiple sliders are created using this function for each SGBM parameter, and they are placed in the `slider_frame` one below the other.

```
def create_slider(label, from_, to, resolution=1, default=None, length=200):
    global slider_row # Access the global slider_row variable

    slider = tk.Scale(slider_frame, from_=from_, to=to, resolution=resolution, orient=tk.HORIZONTAL,
                      label=label, length=length, command=update_disparity_map)
    if default is not None:
        slider.set(default)
    slider.grid(row=slider_row, column=0, sticky="ew", pady=5)

    slider_row += 1
    return slider

blockSize_slider = create_slider("blockSize (odd)", 3, 255, 2, 21)
preFilterCap_slider = create_slider("preFilterCap", 1, 63, default=29)
minDisparity_slider = create_slider("minDisparity", -100, 100, default=-30)
numDisparities_slider = create_slider("numDisparities", 16, 256, 16, 160)
preFilterSize_slider = create_slider("preFilterSize (odd)", 5, 255, 2, 5)
textureThreshold_slider = create_slider("textureThreshold", 0, 1000, default=100)
uniquenessRatio_slider = create_slider("uniquenessRatio", 0, 100, default=10)
speckleRange_slider = create_slider("speckleRange", 0, 100, default=14)
speckleWindowSize_slider = create_slider("speckleWindowSize", 0, 200, default=100)
P1_slider = create_slider("P1", 0, 1000, default=216)
P2_slider = create_slider("P2", 0, 1000, default=864)
disp12MaxDiff_slider = create_slider("disp12MaxDiff", -1, 255, default=1)
# mode_slider = create_slider("mode", 0, 3, default=3)
```

10. Disparity Label and Canvas:

- A label (`disparity_label`) is created to display the disparity value when the user clicks on the map.
- A canvas (`disparity_canvas`) is created to display the disparity map. It occupies the remaining space in the window and can expand if the window is resized.

```
# Disparity Label
disparity_label = tk.Label(slider_frame, text="Disparity:")
disparity_label.grid(row=slider_row, column=0, sticky="w")

# Disparity Canvas
disparity_canvas = tk.Canvas(window)
disparity_canvas.grid(row=0, column=1, sticky="nsew")
```

11. Load Images and Initialize:

- Attempts to load the stereo images and calls the `update_disparity_map` function to calculate and display the initial disparity map.
- If any error occurs during loading or calculation, it displays an error message in the console and the GUI.

```
# Load images and initialize the disparity map on startup
try:
    left_image = cv2.imread("ImageL_1.bmp", cv2.IMREAD_GRAYSCALE)
    right_image = cv2.imread("ImageR_1.bmp", cv2.IMREAD_GRAYSCALE)
    update_disparity_map() # Initialize and display the disparity map.
except Exception as e:
    print(f"Error: {e}") # Print the error message
    disparity_label.config(text=f"Error: {e}") # Display error in GUI
```

12. Configure Layout and Start Main Loop:

- Configures the grid layout to allow the disparity canvas to expand when the window is resized.
- Starts the Tkinter main event loop, which keeps the window open and responds to user events (like slider changes or mouse clicks).

```
# Configure grid layout
window.grid_rowconfigure(0, weight=1) # Allow image canvas to expand vertically
window.grid_columnconfigure(1, weight=1) # Allow image canvas to expand horizontally

window.mainloop()
```

Key Connections

- Camera Control:** The camera acquisition and setup are identical to the first script, ensuring seamless integration.
- Disparity Map:** The disparity map calculation in `disp.disparityCalculate` likely uses the SGBM algorithm, similar to the second script.
- GUI Integration:** The `disp.createTrackbars` function suggests that the disparity map visualization and depth measurement are done through an interactive GUI, like the third script.
- Depth Measurement:** The `onMouse` function allows the user to click on the disparity map to get the distance of the corresponding point, making the system more interactive.

OBSERVATIONS & RECORDINGS :




Fig. 3: Figure Generated through Blendr (Above), Disparity MAP (Right)










Fig. 4: Photo captured using Camera (Above), Disparity MAP (Right)







**Fig. 7: Externally Smoothened Image (Above)
Disparity Map(Right)**




Fig. 8: Grayscale Image(Above),Disparity MAP(Right)

C

Conclusion

The successful development of this stereo calibration system underscores the efficacy of computer vision techniques in achieving accurate depth perception. The meticulous calibration process, outlined in this documentation, empowers researchers and developers to confidently embark on projects that harness the power of stereo vision.

By leveraging the calibrated parameters and rectification maps obtained through this work, the potential for advancements in diverse fields becomes evident. Real-time disparity calculation can enable robots to navigate complex environments, while precise 3D reconstruction can enhance augmented reality experiences. The system's flexibility facilitates further customization and experimentation, enabling the exploration of advanced algorithms such as semi-global matching (SGBM) or dense matching to enhance depth accuracy.

It is anticipated that continued research and refinement of this calibration framework will pave the way for innovative advancements in various domains, including robotics, autonomous systems, medical imaging, and beyond. The insights and resources provided herein equip researchers and developers with a robust foundation to contribute to the ongoing evolution of stereo vision technology.

A

Appendix

The libraries utilised in this code must be pre installed using the command line using ‘pip’ command:

- Open Command prompt as an admin.
- Type the command: python -m pip install numpy
- Similarly install the other required libraries.

Vimba Camera Setup:

```
import cv2 as cv
import numpy as np
from vmbpy import *
import time
from queue import Queue
from typing import Optional, Callable
import matplotlib.pyplot as plt

# Import custom modules for calibration and disparity calculations
import Calibration
import Disparity
import DISPARITY as disp

# --- Callback Functions ---

def onMouse(event, x, y, flags, disparityNormalized):
    """
    Handles mouse click events on the disparity map.
    Calculates and prints the distance in centimeters at the clicked pixel.
    """
    if event == cv.EVENT_LBUTTONDOWN:
        distance = disparityNormalized[y][x]
        print(f"Distance in Centimeters: {distance}")
        return distance
```

```

# --- Camera Setup and Configuration ---

opencv_display_format = PixelFormat.Bgr8 # Preferred pixel format for OpenCV display

def get_camera():
    """
    Retrieves all available cameras from the Vimba system.
    Raises an error if no cameras are found.
    """
    with VmbSystem.get_instance() as vmb:
        cameras = vmb.get_all_cameras()
        if not cameras:
            raise RuntimeError("No cameras detected")
        return cameras

def setup_camera(cam: Camera):
    """
    Configures common camera settings:
    - Sets exposure to automatic .
    - Sets white balance to automatic .
    - Adjusts packet size for optimal streaming .
    """
    with cam:
        try:
            cam.ExposureAuto.set("Continuous")
            cam.BalanceWhiteAuto.set("Continuous")

            stream = cam.get_stream()[0] # Assuming one stream per camera
            stream.GVSPAdjustPacketSize.run()
            while not stream.GVSPAdjustPacketSize.is_done(): # Wait for adjustment to complete
                pass
        except (AttributeError, VmbFeatureError) as e:
            print(f"Warning: Failed to set up camera feature: {e}") # Log any issues

class Handler:
    """
    Handles incoming frames from the camera stream.
    - Queues frames for display in the correct format.
    """
    def __init__(self):
        self.display_queue = Queue(10)

    def get_image(self):
        """Retrieves the next image from the queue (blocking)."""
        return self.display_queue.get(True)

```

```

def __call__(self, cam: Camera, stream: Stream, frame: Frame):
    """
    Callback function called for each frame received from the camera.
    Converts the frame to the desired format and puts it in the display queue.
    """
    if frame.get_status() == FrameStatus.Complete:
        print(f"{cam} acquired {frame}", flush=True)

    if frame.get_pixel_format() != opencv_display_format:
        frame = frame.convert_pixel_format(opencv_display_format)

    self.display_queue.put(frame.as_opencv_image(), True)
    cam.queue_frame(frame) # Re-queue the frame

```

--- Trigger Functions ---

```

def triggerCamera(camera):
    """
    Configures camera for software triggering (implementation not shown).
    """
    pass

def trigger(camera):
    """
    Triggers the camera to capture a frame (implementation not shown).
    """
    pass

```

--- Main Program ---

```

with VmbSystem.get_instance() as vmb:

    # Get and setup the first two cameras
    cameras = get_camera()
    if len(cameras) < 2:
        raise RuntimeError("Need at least two cameras for stereo vision")

    with cameras[0] as camL, cameras[1] as camR:
        setup_camera(camR)
        setup_camera(camL)

        # Configure triggering and set manual exposure
        triggerCamera(camL)
        triggerCamera(camR)
        camR.ExposureAuto.set("Off")
        camR.ExposureTime.set(20000)
        camL.ExposureAuto.set("Off")
        camL.ExposureTime.set(20000)

```

```

# ... (Load default camera settings if needed)

# Start video streaming with handlers
handlerR = Handler()
handlerL = Handler()
camR.start_streaming(handler=handlerR, buffer_count=10)
camL.start_streaming(handler=handlerL, buffer_count=10)

# Display loop
msg = "Stream from 'l'. Press 'q' to quit, 's' to save images"
counter = 0
size = (640, 480) # Desired display size
while True:
    # Get images from the queues
    imageR = cv.resize(handlerR.get_image(), size)
    imageL = cv.resize(handlerL.get_image(), size)

    grayR = cv.cvtColor(imageR, cv.COLOR_BGR2GRAY)
    grayL = cv.cvtColor(imageL, cv.COLOR_BGR2GRAY)

    # Display the images
    cv.imshow(msg.format(camR.get_name()), grayR) # Right camera
    cv.imshow(msg.format(camL.get_name()), grayL) # Left camera

    key = cv.waitKey(1)
    if key == ord("q"): # Quit on 'q'
        break
    elif key == ord("s"): # Save images on 's'
        print("Images Saved!!!")
        counter += 1
        # ... (Save the images to desired location)

# Cleanup on exit
cv.destroyAllWindows()
camR.stop_streaming()
camL.stop_streaming()

```

Stereo Calibration:

```

import cv2 as cv
import numpy as np
import glob

def StereoCalibration():
    ##### FIND CHESSBOARD CORNERS #####
    boardsize = (9,7)
    framesize = (640,480)

    # termination criteria
    criteria = (cv.TERM_CRITERIA_EPS + cv.TERM_CRITERIA_MAX_ITER, 30, 0.001)

    #prepare object points with numpy
    objP = np.zeros((boardsize[0]*boardsize[1],3), np.float32)
    objP[:,2] = np.mgrid[0:boardsize[0],0:boardsize[1]].T.reshape(-1,2)

    # Arrays to store object points and image points from all the images.
    objPoints = [] # 3d point in real world space
    imgPointsL = [] # 2d points in image plane of camera1.
    imgPointsR = [] # 2d points in image plane of camera0.

    imagesL = glob.glob("S:\Bin Picking Project\TEST\CamL\*.bmp")
    imagesR = glob.glob("S:\Bin Picking Project\TEST\CamR\*.bmp")

    for imageL, imageR in zip(imagesL, imagesR):

        imgL = cv.imread(imageL)
        imgR = cv.imread(imageR)

        grayL = cv.cvtColor(imgL, cv.COLOR_BGR2GRAY)
        grayR = cv.cvtColor(imgR, cv.COLOR_BGR2GRAY)

        #Find corners in the chessboard
        retL, cornersL = cv.findChessboardCorners(grayL, boardsize, None)
        retR, cornersR = cv.findChessboardCorners(grayR, boardsize, None)

        print(retL, retR)
        # If corners are found, add object points and image points
        if retL and retR == True:
            objPoints.append(objP)

```

```

#append the chessboard corner point to imagepoints
cornersL = cv.cornerSubPix(grayL, cornersL, (11,11),(-1,-1), criteria)
imgPointsL.append(cornersL)
cornersR = cv.cornerSubPix(grayR, cornersR, (11,11),(-1,-1), criteria)
imgPointsR.append(cornersR)

# draw and display the corners
cv.drawChessboardCorners(imgL, boardsize,cornersL, retL)
cv.imshow("LEFT_img", imgL)
cv.drawChessboardCorners(imgR, boardsize,cornersR, retR)
cv.imshow("RIGHT_img", imgR)

cv.waitKey(3000)

cv.destroyAllWindows()

#####
#CALIBRATION #####
#Camera1 Calibration
    calibration1L, cameraMatrixL, distortionL, rotVectorL, transVectorL =
cv.calibrateCamera(objPoints, imgPointsL, grayL.shape[::1], None, None)
heightL, widthL, channelsL = imgL.shape
# # #### Returns the new camera intrinsic matrix based on the free scaling parameter.
    newCameraMatrixL, roi_L = cv.getOptimalNewCameraMatrix(cameraMatrixL,
distortionL,(widthL, heightL), 1, (widthL, heightL))

# Camera2 Calibration
    calibrationR, cameraMatrixR, distortionR, rotVectorR, transVectorR =
cv.calibrateCamera(objPoints, imgPointsR, grayR.shape[::1], None, None)
heightR, widthR, channelsR = imgR.shape
# # #### Returns the new camera intrinsic matrix based on the free scaling parameter.
    newCameraMatrixR, roi_R = cv.getOptimalNewCameraMatrix(cameraMatrixR,
distortionR,(widthR, heightR), 1, (widthR, heightR))

#####
# Stereo Vision Calibration #####
flags = 0
flags |= cv.CALIB_FIX_INTRINSIC
# here we fix the intrinsic camera matrices so that only Rotation, translation essential and
fundamental matrices
# so the intrinsic parameters are the same

```

```

ret, newCameraMatrixL, distCoeffsL, newCameraMatrixR, distCoeffsR, rotMatrix, transVector,
essMatrix, fundMatrix = cv.stereoCalibrate(objPoints, imgPointsL, imgPointsR,
newCameraMatrixL, distortionL,
                                         newCameraMatrixR,
distortionR, grayR.shape[::-1], criteria=criteria, flags=flags)

#####
##### Stereo Rectification #####
## Computes rectification transforms for each head of a calibrated stereo camera
### alpha = 1
### alpha=0 means that the rectified images are zoomed and shifted
rectifyScale = 1
rectTransL, rectTransR, projMatrixL, projMatrixR, disp2DepthMapMatrix, roiL, roiR =
cv.stereoRectify(newCameraMatrixL, distCoeffsL, newCameraMatrixR, distCoeffsR,
grayR.shape[::-1], rotMatrix, transVector, rectifyScale, (0,0))

stereoMapLx, stereoMapLy = cv.initUndistortRectifyMap(cameraMatrixL, distCoeffsL, rotMatrix,
projMatrixL, grayL.shape[::-1], cv.CV_32FC1)

stereoMapRx, stereoMapRy = cv.initUndistortRectifyMap(cameraMatrixR, distCoeffsR,
rotMatrix, projMatrixR, grayR.shape[::-1], cv.CV_32FC1)

print("Saving Calibration Parameters")
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\cameraMatrixLeft.npy',
cameraMatrixL)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\cameraMatrixRight.npy',
cameraMatrixR)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\newcameraMatrixLeft.npy',
newCameraMatrixL)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\newcameraMatrixRight.npy',
newCameraMatrixR)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\Distortion_CoefficientLeft.npy',
distCoeffsL)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\Distortion_CoefficientRight.npy',
distCoeffsR)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\RotationMatrixLR.npy',
rotMatrix)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\TranslationVectorLR.npy',
transVector)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\projectionMatrixLeft.npy',
projMatrixL)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\projectionMatrixRight.npy',
projMatrixR)
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\rotationMatrixLeft.npy',
rectTransL)

```

```
np.save('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\rotationMatrixRight.npy',  
rectTransR)

np.save('S:\Bin  
PickingProject\TEST\pixel2WCos\calibParams\disparity2depthMapMatrix.npy',disp2DepthMapMat  
rix)
print("saving Parameters")
cv_file = cv.FileStorage('S:\Bin Picking Project\TEST\pixel2WCos\calibParams\stereoMap.xml',  
cv.FILE_STORAGE_WRITE)

cv_file.write('stereoMapL_x', stereoMapLx)
cv_file.write('stereoMapL_y', stereoMapLy)
cv_file.write('stereoMapR_x', stereoMapRx)
cv_file.write('stereoMapR_y', stereoMapRy)

cv_file.release()

StereoCalibration()
```

Stereo Rectification:

```

import sys
import cv2 as cv
import numpy as np

# --- Load Calibration Parameters ---
camMatrix0=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/cameraMatrixLeft.npy') =
camMatrix1=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/cameraMatrixRight.npy') =
distcoef0=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/Distortion_CoefficientLeft.n
py') =
distcoef1=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/Distortion_CoefficientRight.n
py') =
newCamMat0=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/newcameraMatrixLeft.npy') =
newCamMat1=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/newcameraMatrixRight.npy') =
rectTransL=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/rotationMatrixLeft.npy') =
rectTransR=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/rotationMatrixRight.npy') =
projMatrixL=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/projectionMatrixLeft.npy') =
projMatrixR=
np.load('C:/Users/localuser/Documents/test/pixel2WCos/calibParams/projectionMatrixRight.npy') =

```

--- Image Undistortion and Rectification Functions ---

```
def undistort(image0, image1):
```

```
    """
```

Undistorts a pair of stereo images based on loaded camera parameters.

This function applies lens distortion correction to both input images using the calibration matrices (`camMatrix0`, `camMatrix1`) and distortion coefficients (`distcoef0`, `distcoef1`) obtained during calibration.

The new camera matrices (`newCamMat0`, `newCamMat1`) might be used for optimal undistortion if they were computed during calibration.

Args:

image0: The left image (numpy array).

image1: The right image (numpy array).

Returns:

- undistorted0: The undistorted left image.
- undistorted1: The undistorted right image.

```
undistorted0 = cv.undistort(image0, camMatrix0, distcoef0, None, newCamMat0)
undistorted1 = cv.undistort(image1, camMatrix1, distcoef1, None, newCamMat1)
return undistorted0, undistorted1
```

def undistortRectify(imageL, imageR):

Undistorts and rectifies a pair of stereo images.

This function first calculates rectification maps based on the loaded calibration parameters. It then uses these maps to undistort and rectify the input images, making the epipolar lines parallel for easier stereo correspondence calculations.

Args:

- imageL: The left image (numpy array).
- imageR: The right image (numpy array).

Returns:

- undistortedL: The undistorted and rectified left image.
- undistortedR: The undistorted and rectified right image.

```
# Initialize rectification maps
```

```
stereoMapL_x, stereoMapL_y = cv.initUndistortRectifyMap(
    camMatrix0, distcoef0, rectTransL, projMatrixL, (640, 480), cv.CV_32FC1
)
```

```
stereoMapR_x, stereoMapR_y = cv.initUndistortRectifyMap(
    camMatrix1, distcoef1, rectTransR, projMatrixR, (640, 480), cv.CV_32FC1
)
```

```
# Undistort and rectify images using the maps
```

```
undistortedL = cv.remap(imageL, stereoMapL_x, stereoMapL_y, cv.INTER_LINEAR)
undistortedR = cv.remap(imageR, stereoMapR_x, stereoMapR_y, cv.INTER_LINEAR)
```

```
return undistortedL, undistortedR
```

Disparity:

```

import cv2 as cv
import numpy as np
import glob
import sys
import matplotlib.pyplot as plt

# --- Calibration Parameters ---
boardSize = (7, 9) # Inner corners on chessboard (horizontal, vertical)
frameSize = (640, 480) # Image resolution (width, height)
criteria = (cv.TERM_CRITERIA_EPS + cv.TERM_CRITERIA_MAX_ITER, 30, 0.001) # Termination criteria for corner refinement

# --- 3D Object Points (Chessboard Corners) ---
objp = np.zeros((boardSize[0] * boardSize[1], 3), np.float32) # Create a grid of 3D points (z=0 for flat chessboard)
objp[:, :2] = np.mgrid[0:boardSize[0], 0:boardSize[1]].T.reshape(-1, 2) # Fill with corner coordinates

# --- Storage for Calibration Data ---
objPoints = [] # 3D points in real world space
imgPointsL = [] # 2D points in left image plane
imgPointsR = [] # 2D points in right image plane

# --- Function: Camera Calibration ---
def calibrate_camera(images, boardSize, frameSize, criteria):
    """
    Calibrates a single camera using a set of chessboard images.

    Args:
        images: List of image file paths.
        boardSize: Size of the chessboard (inner corners).
        frameSize: Image resolution (width, height).
        criteria: Termination criteria for corner refinement.

    Returns:
        ret: Calibration success flag.
        mtx: Camera matrix (intrinsic parameters).
        dist: Distortion coefficients.
        rvecs: Rotation vectors (extrinsic parameters).
        tvecs: Translation vectors (extrinsic parameters).
    """
    objpoints = []

```

```

imgpoints = []

for image in images:
    img = cv.imread(image)
    gray = cv.cvtColor(img, cv.COLOR_BGR2GRAY)

    # Find chessboard corners
    ret, corners = cv.findChessboardCorners(gray, boardSize, None)

    if ret:
        # Refine corner locations to subpixel accuracy
        corners2 = cv.cornerSubPix(gray, corners, (11, 11), (-1, -1), criteria)

        # Store object points and image points
        objpoints.append(objp)
        imgpoints.append(corners2)

        # Visualize corners (optional for debugging)
        img = cv.drawChessboardCorners(img, boardSize, corners2, ret)
        cv.imshow('img', img)
        cv.waitKey(500)

cv.destroyAllWindows()

# Calibrate camera
ret, mtx, dist, rvecs, tvecs = cv.calibrateCamera(objpoints, imgpoints, frameSize, None, None)
return ret, mtx, dist, rvecs, tvecs

# --- Function: Disparity Map and Depth Estimation ---
def disparityMap(imageL, imageR):
    """
    Calculates the disparity map and depth information from a pair of rectified stereo images.

    Args:
        imageL: Rectified left image.
        imageR: Rectified right image.

    Returns:
        disparity: Disparity map (pixel differences between corresponding points).
        depth: Depth map (estimated distances to scene points).
    """
    # Create StereoBM object and set parameters
    ndispFactor = 18 # Disparity search range multiplier
    stereo = cv.StereoBM_create(numDisparities=0 * ndispFactor, blockSize=21)

```

```

stereo.setTextureThreshold(10) # Filter out areas with low texture
stereo.setSpeckleRange(1000) # Reduce speckles in the disparity map

# Compute disparity
disparity = stereo.compute(imageL, imageR)

# Load pre-computed disparity-to-depth transformation matrix
disp2depthmapMat = np.load('S:\Bin  
Project\TEST\pixel2WCos\disparity2depthMapMatrix.npy') Picking

# Normalize and visualize disparity (optional for debugging)
disp_norm = cv.normalize(disparity, None, alpha=0, beta=255, norm_type=cv.NORM_MINMAX,  
dtype=cv.CV_8U)
disp_norm = cv.applyColorMap(disp_norm, cv.COLORMAP_JET)

# Calculate depth map
depth = cv.reprojectImageTo3D(disparity, disp2depthmapMat)

return disparity, depth

# --- Function: Mouse Callback for Depth Measurement
def onMouse(event, x, y, flag, disparityNormalized):
    """
    Handles mouse events to display depth information at the clicked point.
    """
    if event == cv.EVENT_LBUTTONDOWN:
        distance = disparityNormalized[y][x]
        print("Distance in Centimeters:", distance)
        return distance

# --- Function: Enhanced Depth Map Calculation with StereoSGBM and WLS Filtering ---
def depth_map(imgL, imgR, Q, leftMapX, leftMapY, rightMapX, rightMapY):
    """
    Calculates a refined depth map using StereoSGBM and Weighted Least Squares (WLS)
    filtering.
    """

Args:
    imgL: Rectified left image.
    imgR: Rectified right image.
    Q: Disparity-to-depth mapping matrix (from stereoRectify).
    leftMapX, leftMapY: Remapping maps for the left image.
    rightMapX, rightMapY: Remapping maps for the right image.

Returns:

```

```

filteredImg: Filtered disparity map (for visualization).
points_3D: 3D point cloud in the camera coordinate system.
"""

# ... (SGBM parameters and setup, image remapping, disparity calculation, WLS filtering, etc.)

def depth_map(imgL, imgR, Q, leftMapX, leftMapY, rightMapX, rightMapY):
    window_size = 3 # SGBM Parameters
    left_matcher = cv.StereoSGBM_create(
        minDisparity=-1,
        numDisparities=5*16,
        blockSize=window_size,
        P1=8 * 3 * window_size,
        P2=32 * 3 * window_size,
        disp12MaxDiff=12,
        uniquenessRatio=10,
        speckleWindowSize=50,
        speckleRange=32,
        preFilterCap=63,
        mode=cv.STEREO_SGBM_MODE_SGBM_3WAY
    )
    right_matcher = cv.ximgproc.createRightMatcher(left_matcher)
    lmbda = 80000
    sigma = 1.3

    wls_filter = cv.ximgproc.createDisparityWLSFilter(matcher_left=left_matcher)
    wls_filter.setLambda(lmbda)
    wls_filter.setSigmaColor(sigma)

# Rectify Images
imgL = cv.remap(imgL, leftMapX, leftMapY, cv.INTER_LINEAR)
imgR = cv.remap(imgR, rightMapX, rightMapY, cv.INTER_LINEAR)

# Disparity Calculation and Filtering
disparity = left_matcher.compute(imgL, imgR)
disparity = np.int16(disparity)
filteredImg = wls_filter.filter(disparity, imgL, None, None)

# Convert to Depth Map
points_3D = cv.reprojectImageTo3D(filteredImg, Q)

# Normalize for Visualization
    filteredImg = cv.normalize(src=filteredImg, dst=filteredImg, beta=0, alpha=255,
norm_type=cv.NORM_MINMAX)
    filteredImg = np.uint8(filteredImg)

```

```

return filteredImg, points_3D

# --- Main Program ---
if __name__ == "__main__":
    # Check if image paths were provided as arguments
    if len(sys.argv) < 3:
        print("Usage: python your_script.py <left_image_path> <right_image_path>")
        sys.exit(1)

    left_image_path = sys.argv[1]
    right_image_path = sys.argv[2]

    # Load and Preprocess Images (After Calibration)
    imagesR = cv.imread(right_image_path)
    imagesL = cv.imread(left_image_path)

    if imagesR is None or imagesL is None:
        raise ValueError("Error loading images. Check file paths and ensure images are valid.")

    imageSize = imagesL.shape[:2]

    # Load Images (For Both Cameras)
    imagesL_cali = glob.glob(r"S:\Bin Picking Project\TEST\CamL\*.bmp")
    imagesR_cali = glob.glob(r"S:\Bin Picking Project\TEST\CamR\*.bmp")

    # Camera Calibration
    retL, mtxL, distL, rvecsL, tvecsL = calibrate_camera(imagesL_cali, boardSize, frameSize, criteria)
    retR, mtxR, distR, rvecsR, tvecsR = calibrate_camera(imagesR_cali, boardSize, frameSize, criteria)

    # Check if there are enough points for calibration
    if len(objPoints) < 2:
        print("Not enough calibration images found. Please use at least 2 images.")
        exit()

    # Stereo Calibration
    flags = 0
    flags |= cv.CALIB_FIX_INTRINSIC
    criteria_stereo = (cv.TERM_CRITERIA_EPS + cv.TERM_CRITERIA_MAX_ITER, 30, 0.001)

    retS, newCameraMatrixL, distCoeffsL, newCameraMatrixR, distCoeffsR, R, T, E, F =
    cv.stereoCalibrate(
        objPoints, imgPointsL, imgPointsR, mtxL, distL, mtxR, distR,

```

```

    imageSize, criteria_stereo, flags
)
if not retS:
    raise ValueError("Stereo calibration failed. Check your calibration images and settings.")

# Stereo Rectification
rectify_scale = 1
R1, R2, P1, P2, Q, validPixROI1, validPixROI2 = cv.stereoRectify(
    newCameraMatrixL, distCoeffsL, newCameraMatrixR, distCoeffsR,
    imageSize, R, T, rectify_scale, (0, 0)
)
left_map1, left_map2 = cv.initUndistortRectifyMap(newCameraMatrixL, distCoeffsL, R1, P1,
imageSize, cv.CV_16SC2)
right_map1, right_map2 = cv.initUndistortRectifyMap(newCameraMatrixR, distCoeffsR, R2, P2,
imageSize, cv.CV_16SC2)

# Calculate Disparity and Depth Map (Pass rectification maps)
disparity, points_3D = depth_map(imagesL, imagesR, Q, left_map1, left_map2, right_map1,
right_map2)

# Visualization
plt.imshow(disparity, 'gray')
plt.title('Disparity Map')
plt.show()

```

Disparity GUI:

```

import tkinter as tk #Library used for making GUI
import cv2
import numpy as np
from PIL import Image, ImageTk

# --- Image Loading and Error Handling ---

# Load stereo images (BMP format)
try:
    left_image = cv2.imread("ImageL_1.bmp", cv2.IMREAD_GRAYSCALE)
    right_image = cv2.imread("ImageR_1.bmp", cv2.IMREAD_GRAYSCALE)
except Exception as e:
    print(f"Error loading images: {e}")
    exit() # Exit the program if images can't be loaded

# Validate image loading
if left_image is None or right_image is None:
    print("Error: Could not load one or both of the images.")
    exit()

# --- Disparity Map Initialization ---

disparity = None      # Initialize disparity map (will be calculated later)
disparity_color = None # Initialize color-mapped disparity map (for visualization)

# Create StereoSGBM object for disparity calculation (SGBM_3WAY mode)
stereo = cv2.StereoSGBM_create(mode=3) # Using StereoSGBM algorithm for depth estimation

# --- Mouse Callback Function ---

def on_mouse(event, x, y, flags, param):
    """
    Handles mouse events on the disparity map canvas.
    Displays the disparity value at the clicked point if valid.
    """

    global disparity
    if event == cv2.EVENT_LBUTTONDOWN and disparity is not None:
        # Check for valid coordinates
        if 0 <= y < disparity.shape[0] and 0 <= x < disparity.shape[1]:
            # Disparity values are scaled by 16, so divide by 16 for actual value
            disparity_value = disparity[y, x] / 16.0

```

```

if disparity_value > 0: # Ensure valid disparity
    disparity_label.config(text=f"Disparity: {disparity_value:.2f}")

# --- Disparity Map Update Function ---

def update_disparity_map(*args):
    """
    Updates the disparity map based on slider values and displays it on the canvas.
    """
    global disparity, disparity_color

# --- Get and Validate Slider Values ---
block_size = blockSize_slider.get()
if block_size % 2 == 0:    # Ensure block size is odd
    block_size += 1
preFilterSize = preFilterSize_slider.get()
if preFilterSize % 2 == 0:  # Ensure pre-filter size is odd
    preFilterSize += 1

# --- Set StereoSGBM Parameters ---
stereo.setBlockSize(block_size)
stereo.setPreFilterCap(preFilterCap_slider.get())
stereo.setMinDisparity(minDisparity_slider.get())
stereo.setNumDisparities(numDisparities_slider.get())
textureThreshold = textureThreshold_slider.get()
uniquenessRatio = uniquenessRatio_slider.get()
speckleRange = speckleRange_slider.get()
speckleWindowSize = speckleWindowSize_slider.get()
P1 = P1_slider.get()
P2 = P2_slider.get()
disp12MaxDiff = disp12MaxDiff_slider.get()

# --- Compute Disparity Map ---
disparity = stereo.compute(left_image, right_image)

# --- Normalize and Visualize ---
# Normalize for 0-255 range for better visualization
disparity_normalized = cv2.normalize(disparity, None, 0, 255, cv2.NORM_MINMAX,
cv2.CV_8UC1)
disparity_color = cv2.applyColorMap(disparity_normalized, cv2.COLORMAP_JET) # Apply JET
colormap

# --- Display on Canvas ---


```

```

disparity_image = Image.fromarray(disparity_color)
disparity_photo = ImageTk.PhotoImage(disparity_image)

# Update canvas dimensions to fit the image
disparity_canvas.config(width=disparity_image.width, height=disparity_image.height)
disparity_canvas.delete("all") # Clear previous content
disparity_canvas.create_image(0, 0, anchor=tk.NW, image=disparity_photo)

# Keep a reference to avoid garbage collection of the image
disparity_canvas.image = disparity_photo
disparity_canvas.bind("<Button-1>", on_mouse) # Enable mouse clicks for disparity display

```

--- GUI Setup ---

```

window = tk.Tk()
window.title("Disparity Map GUI")

# Create a frame to hold all the sliders
slider_frame = tk.Frame(window)
slider_frame.grid(row=0, column=0, sticky="ns") # Position the frame on the left side

```

--- Slider Creation Helper Function ---

```

slider_row = 0 # Initialize the row counter for placing sliders

def create_slider(label, from_, to, resolution=1, default=None, length=200):
    """

```

Helper function to create a slider widget with a label.

Args:

- label: Text to display next to the slider.
- from_: Minimum value for the slider.
- to: Maximum value for the slider.
- resolution: Step size for the slider (default 1).
- default: Initial value of the slider (default None).
- length: Length of the slider (default 200).

Returns:

- The created slider widget.

```

global slider_row # Use the global row counter

```

```

slider = tk.Scale(
    slider_frame,

```

```

from_=from_,
to=to,
resolution=resolution,
orient=tk.HORIZONTAL, # Horizontal orientation
label=label,
length=length,
command=update_disparity_map # Call update_disparity_map on change
)
if default is not None: # Set default value if provided
    slider.set(default)
    slider.grid(row=slider_row, column=0, sticky="ew", pady=5) # Place in grid, expand horizontally,
add padding

slider_row += 1 # Increment row for the next slider
return slider

```

--- Create Sliders ---

```

# Each slider controls a parameter of the StereoSGBM algorithm or its visualization
blockSize_slider = create_slider("Block Size (odd)", 3, 255, 2, 21) # Block size for matching (odd
values only)
preFilterCap_slider = create_slider("Pre-Filter Cap", 1, 63, default=29) # Pre-filtering threshold
minDisparity_slider = create_slider("Min Disparity", -100, 100, default=-30) # Minimum possible
disparity value
numDisparities_slider = create_slider("Num Disparities", 16, 256, 16, 160) # Number of disparity
values (multiple of 16)
preFilterSize_slider = create_slider("Pre-Filter Size (odd)", 5, 255, 2, 5) # Pre-filtering window size
(odd values only)
textureThreshold_slider = create_slider("Texture Threshold", 0, 1000, default=100) # Threshold for
texture filtering
uniquenessRatio_slider = create_slider("Uniqueness Ratio", 0, 100, default=10) # Uniqueness
ratio for matching
speckleRange_slider = create_slider("Speckle Range", 0, 100, default=14) # Maximum
allowed difference between disparity values
speckleWindowSize_slider = create_slider("Speckle Window Size", 0, 200, default=100) # Window size for speckle removal
P1_slider = create_slider("P1", 0, 1000, default=216) # Penalty for disparity change by +/- 1
between pixels
P2_slider = create_slider("P2", 0, 1000, default=864) # Penalty for disparity change by more than
+/- 1 between pixels
disp12MaxDiff_slider = create_slider("Disp12 Max Diff", -1, 255, default=1) # Maximum allowed
difference between left and right disparities

```

--- Disparity Label ---

```

disparity_label = tk.Label(slider_frame, text="Disparity:")
disparity_label.grid(row=slider_row, column=0, sticky="w")

# --- Disparity Canvas ---
# Create a canvas to display the disparity map
disparity_canvas = tk.Canvas(window)
disparity_canvas.grid(row=0, column=1, sticky="nsew") # Place on the right side, allow expansion

# --- Initial Disparity Map Display ---

# Load images and initialize the disparity map on startup
try:
    left_image = cv2.imread("ImageL_1.bmp", cv2.IMREAD_GRAYSCALE)
    right_image = cv2.imread("ImageR_1.bmp", cv2.IMREAD_GRAYSCALE)
    update_disparity_map() # Initialize and display the disparity map
except Exception as e:
    print(f"Error: {e}")
    disparity_label.config(text=f"Error: {e}") # Display error in GUI

# --- Grid Layout Configuration ---
# Make the image canvas expandable
window.grid_rowconfigure(0, weight=1)
window.grid_columnconfigure(1, weight=1)

window.mainloop() # Start the GUI main loop

```



References

Vimba Camera SDK and Python Bindings

- Vimba Python Manual (VmbPy):
 - Download:
https://www.alliedvision.cn/fileadmin/content/documents/products/software/software/Vimba/docu/manuals/Vimba_Python_Manual.pdf
 - GitHub:
<https://github.com/alliedvision/VimbaPython/blob/master/Documentation/Vimba%20Python%20Manual.pdf>
- Allied Vision Developer Guide (Python API Manual):
 - Online:
https://docs.alliedvision.com/Vimba_DeveloperGuide/pythonAPIManual.html

OpenCV for Image Processing

- OpenCV Documentation:
 - Online: <https://docs.opencv.org/4.x/index.html>
- OpenCV-Python Tutorials:
 - Online: https://docs.opencv.org/4.x/d6/d00/tutorial_py_root.html
 - Online: https://docs.opencv.org/4.x/dc/dbb/tutorial_py_calibration.html

Stereo Vision

- Stereo Vision Tutorial (OpenCV):
 - Online: https://docs.opencv.org/3.4/dd/d53/tutorial_py_depthmap.html

Disparity Calculation Algorithms

- Stereo Block Matching (StereoBM):
 - OpenCVDocumentation:
https://docs.opencv.org/4.x/d9/dba/classcv_1_1StereoBM.html
- Semi-Global Block Matching (StereoSGBM):
 - OpenCVDocumentation:
https://docs.opencv.org/4.x/d2/d85/classcv_1_1StereoSGBM.html
- Weighted Least Squares (WLS) Filter:
 - OpenCVDocumentation:
https://docs.opencv.org/4.x/d3/d14/tutorial_ximgproc_disparity_filtering.html

GUI Frameworks

- Tkinter Documentation:
 - Online: <https://docs.python.org/3/library/tkinter.html>
- Matplotlib Documentation:
 - Online: <https://matplotlib.org/stable/contents.html>

Additional Resources

- Stack Overflow
- Allied Vision Support Forum: <https://forum.alliedvision.com/>